developing solutions











Operating manual

FT90

Humidity and temperature measuring device PRO-LINE®

with optional (differential) pressure measurement





Masthead

Manufacturer: FISCHER Mess- und Regeltechnik GmbH

Bielefelderstr. 37a D-32107 Bad Salzuflen Telephone: +49 5222 974 0 Telefax: +49 5222 7170

eMail: <u>info@fischermesstechnik.de</u> web: <u>www.fischermesstechnik.de</u>

Technical editorial team: Documentation representative: T. Malischewski

Technical editor: R. Kleemann

All rights, also those to the translation, reserved. No part of this document may be reproduced or processed, duplicated or distributed using electronic systems or any other form (print, photocopy, microfilm or another process) without the written consent of the company FISCHER Mess- und Regeltechnik GmbH, Bad Salzuflen.

Reproduction for internal use is expressly allowed.

Brand names and procedures are used for information purposes only and do not take the respective patent situation into account. Great care was taken when compiling the texts and illustrations; Nevertheless, errors cannot be ruled out. The company FISCHER Mess- und Regeltechnik GmbH will not accept any legal responsibility or liability for this.

Subject to technical amendments.

© FISCHER Mess- und Regeltechnik 2020

Version history

Rev. ST4-A 03/20	Version 1 (first edition)
Rev. ST4-B 08/20	Version 2 order code changed
Rev. ST4-C 09/20	Version 3: Passwords
Rev. ST4-D 11/21	Version 4 accessories (cable length for sensors changed)
Rev. ST4-E 04/22	Version 5 Techn. Data corrected for temperature sensor FF90
Rev. ST4-F 10/22	Version 6 UKCA conformity
Rev. ST4-G 05/23	Version 7 process connection G½ added, ATEX sensor connection changed, mounting flange changed
Rev. ST4-H 02/24	Version 8 Change to sensor: FF12 added, introduction of firmware version >1.41
Rev. ST4-I 07/24	Version 9 (measurement deviation edited and revised, IO-Link)
Rev. ST4-K 11/24	Version 10 (Outdoor application)

Table of contents

1	Saf	ety in	nstructions	7
	1.1	Gene	eral	7
	1.2	onnel Qualification	7	
	1.3	onnel Qualification	7	
	1.4	s due to Non-Observance of Safety Instructions	7	
			ty Instructions for the Operating Company and the Operator	
			ty Instructions for the Operating Company and the Operator	
	1.7	Unau	uthorised Modification	8
	1.8	Inadn	missible Modes of Operation	8
			working practices for maintenance and installation work	
			ogram explanation	
2		`	and functional description	
_			very scope	
			ided use	
	2.2		Explosion hazard area classification	
			External application	
	23		stion diagram	
			gn and mode of operation	
		_	ce versions	
	2.0		Equipment	
		2.0.1	2.5.1.1 Version dP/T/rH	
			2.5.1.2 Version T/rH	
			2.5.1.3 Outlets and interfaces	12
		2.5.2	Process connection	13
		2.5.3		
			ATEX model	
			Type plate	
3			lly	
			eral	
	3.2	Moun	nting in explosive areas	16
	3.3		ess connection	
			Replacement plates	
			Cutting ring screw connections	
	3.4	Electi	trical connections	
		3.4.1		
		3.4.2	Devices only with switch outputs	
			3.4.2.1 Circuit	
			3.4.2.3 M12 connector 1: auxiliary energy and analogue output	
			3.4.2.4 M12 connector 3: Sensor input	
		3.4.3	Devices with switching and analog outputs	
			3.4.3.1 Circuit	
			3.4.3.2 M12 connector 1: auxiliary energy and analogue output	23
			3.4.3.3 M12 connector 2: switch outputs	
			3.4.3.4 M12 connector 3: Sensor input	23

		3.4.4	Devices with Modbus (without switch outputs)	24
			3.4.4.1 Connection to an existing Modbus RTU network	24
			3.4.4.2 Auxiliary energy supply	
			3.4.4.3 M12 plug 1: Modbus IN	26
			3.4.4.4 M12 plug 2: Modbus OUT	26
			3.4.4.5 M12 connector 3: Sensor input	26
		3.4.5	Devices with Modbus (and 4 switch outputs)	26
			3.4.5.1 Connection to an existing Modbus RTU network	27
			3.4.5.2 Auxiliary energy supply	
			3.4.5.3 M12 connector 1: Modbus	
			3.4.5.4 M12 connector 2: Switch outputs	
			3.4.5.5 M12 connector 3: Sensor input	
4	Sta	rt-up		30
	4.1	Instal	lation control	30
	4.2	Switc	h on the measuring device	30
			Measured value display	
		1.2.1	4.2.1.1 2-channel version T/rH	
			4.2.1.2 3-channel version P/T/rH	
			4.2.1.3 Back lighting	
		4.2.2	Keyboard	
	4.3		,)	
			Set menu language	
			Measuring point designation	
			Configuration	
	1 1		ous RTU interface	
			nk Interface	
5	Ope	eratio	n	35
	5.1	First	steps	35
		5.1.1	Passwörter	35
		5.1.2	Operating modes	35
		5.1.3	Menu tree	36
			5.1.3.1 Login	36
			5.1.3.2 Configuration	
			5.1.3.2.1 Configuration -> Channel	
			5.1.3.2.2 Configuration -> Analog output	
			5.1.3.2.3 Configuration -> Switch output	
			5.1.3.3 Info	
			5.1.3.4 Service	
		5.1.4	Navigation in the menu tree	
		_	Path details	
			Input	
		0.1.0	5.1.6.1 Text input	
			5.1.6.2 Value input	
			5.1.6.3 Selection of options	
	52	Main	menu	
			menu	
	5.5	•		
			Log in / log out	
		:1.7 /	Timoout	
			Timeout	

		5.3.3.1	User 1	
			5.3.3.1.1 User 1 permissions	
			Administrator	
	5.3.4	Reset pa	passwords	57
5.4	Confi	guration	1	58
	5.4.1	Input		60
		5.4.1.1	Sensor type	61
	5.4.2	Channe	el 1	62
			2 channel version [temperature]	
			3 channel version [differential pressure]	
			5.4.2.2.1 Mode C1	
			5.4.2.2.2 Measurement C1	
			5.4.2.2.3 Characteristic curve C1 (menu expansion)	
			5.4.2.2.4 Number format C1	
			5.4.2.2.5 Colour change C1	
	5.4.3		el 2	
		5.4.3.1	2 channel version [humidity]	
			5.4.3.1.1 Mode C2	
		5400	5.4.3.1.2 Characteristic C2 (menu expansion)	
			3 channel version [temperature]	
	5.4.4		ii 3	
		5.4.4.1	3 channel version [Humidity]	
			5.4.4.1.1 Mode C3	
	- 4 -	A I		
	5.4.5	Ū	output	
			Analog output 1 type	
			Analog output 1 assignment	
			Signal limits	
	5.4.6		output	
			SP1 assignment	
			SP1 function	
			Switching function	
	5.4.7		[']	
			Language	
			Designation	
			Measuring data display	
			Colour change assignment	
			LCD colour	
			LCD lighting	
	5 4 0		LCD contrast	
	5.4.8		s RTU	
			Baud rate	
			Data format	
			Modbus address	
			Byte order	
5.6	Servi	ce		108
	5.6.1	Firmwar	re update	109
	5.6.2	Replace	e the humidity and temperature sensors	110

6	Servicing	111
	6.1 Maintenance	111
	6.2 Transport	111
	6.3 Service	
	6.4 Disposal	
7	Technical data	112
	7.1 General	
	7.2 Input variables	112
	7.2.1 Temperature and humidity	
	7.2.2 Differential pressure	
	7.3 Output sizes	114
	7.4 Measuring accuracy	115
	7.4.1 Humidity	115
	7.4.2 Temperature	
	7.4.3 Differential pressure	116
	7.5 Digital interfaces	118
	7.6 Auxiliary energy	118
	7.7 Operating conditions	118
	7.8 Display	119
	7.9 Construction design	119
	7.9.1 Materials	120
	7.9.2 Dimensional drawings	120
8	Order code	123
	8.1 Accessories	125
9	Attachments	127
	9.1 EU Declaration of Conformity	
	9.2 UKCA Declaration of Conformity	

1 Safety instructions

1.1 General

This operating manual contains basic instructions for the installation, operation and maintenance of the device that must be followed without fail. It must be read by the installer, the operator and the responsible specialist personnel before installing and commissioning the device.

This operating manual is an integral part of the product and therefore needs to be kept close to the instrument in a place that is accessible at all times to the responsible personnel.

The following sections, in particular instructions about the assembly, commissioning and maintenance, contain important information, non-observance of which could pose a threat to humans, animals, the environment and property.

The instrument described in these operating instructions is designed and manufactured in line with the state of the art and good engineering practice.

1.2 Personnel Qualification

The instrument may only be installed and commissioned by specialized personnel familiar with the installation, commissioning and operation of this product.

Specialized personnel are persons who can assess the work they have been assigned and recognize potential dangers by virtue of their specialized training, their skills and experience and their knowledge of the pertinent standards.

1.3 Personnel Qualification

The instrument may only be installed and commissioned by specialized personnel familiar with the installation, commissioning and operation of this product.

Specialized personnel are persons who can assess the work they have been assigned and recognize potential dangers by virtue of their specialized training, their skills and experience and their knowledge of the pertinent standards.

For explosion-proof models the specialized personnel must have received special training or instruction or be authorized to work with explosion-proof instruments in explosion hazard areas.

1.4 Risks due to Non-Observance of Safety Instructions

Non-observance of these safety instructions, the intended use of the device or the limit values given in the technical specifications can be hazardous or cause harm to persons, the environment or the plant itself.

The supplier of the equipment will not be liable for damage claims if this should happen.

1.5 Safety Instructions for the Operating Company and the Operator

The safety instructions governing correct operation of the instrument must be observed. The operating company must make them available to the installation, maintenance, inspection and operating personnel.

Dangers arising from electrical components, energy discharged by the medium, escaping medium and incorrect installation of the device must be eliminated. See the information in the applicable national and international regulations.

Please observe the information about certification and approvals in the Technical Data section.

BA_EN_FT90 7/132

1.6 Safety Instructions for the Operating Company and the Operator

The safety instructions governing correct operation of the instrument must be observed. The operating company must make them available to the installation, maintenance, inspection and operating personnel.

Dangers arising from electrical components, energy discharged by the medium, escaping medium and incorrect installation of the device must be eliminated. See the information in the applicable national and international regulations.

Please observe the information about certification and approvals in the Technical Data section.

The instrument must be decommissioned and secured against inadvertent reoperation if a situation arises in which it must be assumed that safe operation is no longer possible. Reasons for this assumption could be:

- · evident damage to the instrument
- · failure of the electrical circuits
- · longer storage outside the approved temperature range.
- · considerable strain due to transport

Repairs may be carried out by the manufacturer only.

A professional single conformity inspection as per DIN EN 61010, section 1, must be carried out before the instrument can be re-commissioned. This inspection must be performed at the manufacturer's location. Correct transport and storage of the instrument are required.

1.7 Unauthorised Modification

Modifications of or other technical alterations to the instrument by the customer are not permitted. This also applies to replacement parts. Only the manufacturer is authorised to make any modifications or changes.

1.8 Inadmissible Modes of Operation

The operational safety of this instrument can only be guaranteed if it is used as intended. The instrument model must be suitable for the medium used in the system. The limit values given in the technical data may not be exceeded.

The manufacturer is not liable for damage resulting from improper or incorrect use.

1.9 Safe working practices for maintenance and installation work

The safety instructions given in this operating manual, any nationally applicable regulations on accident prevention and any of the operating company's internal work, operating and safety guidelines must be observed.

The operating company is responsible for ensuring that all required maintenance, inspection and installation work is carried out by qualified specialized personnel.

1.10 Pictogram explanation



A DANGER

Type and source of danger

This indicates a **direct** dangerous situation that could lead to death or **serious injury** (highest danger level).

1. Avoid danger by observing the valid safety regulations.



MARNING

Type and source of danger

This indicates a **potentially** dangerous situation that could lead to death or **serious injury** (medium danger level).

1. Avoid danger by observing the valid safety regulations.



A CAUTION

Type and source of danger

This indicates a **potentially** dangerous situation that could lead to slight or serious injury, damage or **environmental pollution** (low danger level).

1. Avoid danger by observing the valid safety regulations.



NOTICE

Note / advice

This indicates useful information of advice for efficient and smooth operation.

BA_EN_FT90 9/132

2 Product and functional description

2.1 Delivery scope

- Differential pressure transmitter FT90 PRO-LINE®
 Version as stated on the type plate with an integrated assembly rail. Attachment screws are not included in the delivery.
- · Operating manual

2.2 Intended use

The FT90 is suitable for the measurement of humidity and temperature in neutral gaseous media. Optionally, the device can be used to measure the pressure, negative pressure, or differential pressure of neutral gaseous media.

Note the specifications in the technical data with regard to media compatibility.

The device may only be used for the purpose stipulated by the manufacturer. The manufacturer will not be liable for damage arising from incorrect or improper use.

2.2.1 Explosion hazard area classification

Devices with the order code **FT90** ## ## ## # 0 # 000 **R1** # # are classified as electrical equipment for use in potentially explosive areas zone 2 (gases and vapours) and/or zone 22 (dusts).

Gas explosion protection

Designation as per Directive 2014/34/EU:

⟨Ex⟩II 3G Ex ec IIC T4 Gc

Dust explosion protection

Designation as per Directive 2014/34/EU:

⟨ II 3D Ex tc IIIB T125°C Dc

 $-20^{\circ}\text{C} \le \text{T}_{amb} \le 60^{\circ}\text{C}$

2.2.2 External application

If the device is intended for outdoor use, we recommend permanently protecting the membrane keypad against UV radiation and using a suitable enclosure or at least the erection of a sufficiently dimensioned canopy as a protection measure against constant rain or snow.

2.3 Function diagram




Fig. 1: Function diagram

2.4 Design and mode of operation

Temperature and humidity measurement

The temperature and humidity measurement is based on a sensor chip with a digital I2C bus interface. The analog measurement data is digitally converted and linearised. The transmitted data is evaluated by the integrated electronics and is transformed into a display, analog output, and up to four switch outputs or output via the optional Modbus output.

Pressure measurement

The pressure measurement is based on a piezo-resistive sensor element that is suitable for measuring overpressure, negative pressure, and differential pressure. The pressures to be compared have a direct effect on a silicon membrane equipped with a measuring bridge.

When the pressure is equal, the measuring membrane is in its idle state. If a pressure difference occurs, the membrane is deflected and a resistance change takes place on the attached measuring bridge. This change is evaluated by the electronics integrated into the device and is transformed into a display, analog output, and up to four switch outputs or is output via the optional Modbus output.

BA_EN_FT90 11/132

2.5 Device versions

2.5.1 Equipment

2.5.1.1 Version dP/T/rH

Inputs	Channel 1	Channel 2	Channel 3
Differential pressure	X		
Temperature		Х	
Humidity			Х

2.5.1.2 Version T/rH

Inputs	Channel 1	Channel 2	Channel 3
Differential pressure			
Temperature	Х		
Humidity		Х	

2.5.1.3 Outlets and interfaces

Standard	dP/T/rH	T/rH	Mod	bus	IO-Link
	3 chan- nels	2 chan- nels	(Opt1)	(Opt2)	
Switch output 1-4	Х	Х		X	Х
USB interface	Х	Х	Х	Х	Х
Options					
Analogue output 1	Х	Х			
Analogue output 2	Х	Х			
Analogue output 3	X				
RS 485 Modbus RTU			Х	X	
IO-Link					Х

12/132 BA_EN_FT90

2.5.2 Process connection




Fig. 2: Process connections

2.5.3 Electrical connection




Fig. 3: Electric connections

BA_EN_FT90 13/132

2.5.4 ATEX model



Fig. 4: ATEX model

14/132 BA_EN_FT90

2.5.5 Type plate




Fig. 5: Humidity/temperature type plate





Fig. 6: Pressure/humidity/temperature type plate

1	Conformity	2	Device type (order code)
3	Basic measuring range	4	Set measuring range
5	Output signal	6	Overload capacity
7	Auxiliary energy	8	Production number
9	Customer item number	10	ATEX marking
11	Special properties	12	Parameter number
13	Circuit diagram for connector 1	14	Circuit diagram for connector 2
15	Data for channel 1	16	Data for channel 2
17	Data for channel 3	18	Parameter number

Explanations of the symbols



BA_EN_FT90 15/132

3 Assembly

3.1 General

The device is designed for installation on assembly plates or wall surfaces. A pre-mounted 35 mm plastic assembly rail is supplied for this purpose. The attachment screws are not included in the delivery.

Alternatively, the device can also be mounted to a 35 mm top-hat rail.




Fig. 7: Assembly

At the factory, the device is calibrated for vertical installation, but the installation position is arbitrary. For any installation positions that are not vertical, the zero-point signal can be corrected via the installed offset correction.

The enclosure protection type IP 65 is only guaranteed, if a suitable power supply cable is used (see accessories).

If the device is intended for outdoor use, we recommend permanently protecting the membrane keypad against UV radiation and using a suitable enclosure or at least the erection of a sufficiently dimensioned canopy as a protection measure against constant rain or snow.

3.2 Mounting in explosive areas

- If operated in explosive areas, the valid local regulations and guidelines for the installation and operation of electrical systems in explosive areas must be observed.
- If units are used in potentially explosive areas, the personnel must receive additional training or briefings or have a permit to work on explosion-protected units in potentially explosive systems.

DANGER! The operator must ensure that any falling objects cannot collide with the installed unit.

Steps must be taken to prevent the impact creating sparks so that the protection class of the casing is no longer guaranteed. This can be avoided by attaching protective cover, a protective housing or similar.

3.3 Process connection

- · By authorized and qualified specialized personnel only.
- The pipes need to be depressurized when the instrument is being connected.
- Appropriate steps must be taken to protect the device from pressure surges.
- · Check that the device is suitable for the medium being measured.
- · Maximum pressures must be observed (cf. Tech. data)

The pressure lines must be kept as short as possible and installed without any tight bends to avoid delays.

The pressure lines must be installed at an inclination so that no water pockets are created. If the required gradient is not reached, water filters need to be installed at suitable points.

The process connections are marked with (+) and (-) symbols on the device. The pressure lines must be mounted according to these symbols.

1. Differential pressure measurement

- Higher pressure
- lower pressure

2. Pressure measurement

- + Pressure
- open

3.3.1 Replacement plates

The device is fitted with different replacement plates depending on the number of measuring channels.




Fig. 8: Replacement plate

These replacement plates are equipped ex-works with the required process connections and the M12 flange connectors for the electrical connection. The user may not make any independent modifications.

BA_EN_FT90 17/132

	Process connection type		size
0	Pneumatic plug connection for hydraulic hoses	Polyamide hose	6 x 4 x 1 mm 8 x 6 x 1 mm
	CK quick-action screw connection for soft hoses	PVC hose TYGON®	6 x 4 x 1 mm 8 x 6 x 1 mm
	cutting ring screw connection for hydraulic tubes (stainless steel)	tube	6 mm outside 8 mm outside

Fig. 9: Process connection table

3.3.2 Cutting ring screw connections

- ▷ In the case of cutting ring screw connections, incorrect installation of the pressure lines can lead to the destruction of the replacement plate due to the acting forces.
- The cutting ring screw connection may not be mounted to the device in one work step.
- 1. Mount the cutting ring using a pre-assembly connecting piece.
- 2. Always use a conventional assembly paste (1) to avoid cold welding of the stainless steel parts.
- 3. Carry out the final assembly work on the device only with a counter-hold. Mount the cutting ring screw connection with a quarter or half-turn of the union nut.




Fig. 10: Counter-hold for cutting ring screw connections

18/132 BA_EN_FT90

⁽¹⁾The assembly paste is not part of the delivery scope nor is it included in the accessories.

3.4 Electrical connections

- By authorized and qualified specialized personnel only.
- When connecting the unit, the national and international electro-technical regulations must be observed.
- Disconnect the system from the mains, before electrically connecting the device.
- · Install the consumer-adapted fuses.
- Do not connect the connector if strained.

3.4.1 Operation in areas at risk of explosion



MARNING

Do not connect the connector if strained


Sparks can be created, the plug is mounted under tension or replaced.

- If the device is operated in potentially explosive atmospheres, the electrical data of the unit and the valid local regulations and guidelines for the installation and operation of electrical systems in potentially explosive atmospheres must be observed (e.g. DIN EN 60079).
- If the device is used in a potentially explosive atmosphere, the personnel must have received additional training/instruction and/or have obtained a permit for working on explosion-proof devices in potentially explosive systems
- A CE-conform mains adapter with a slow 200 mA fuse only may be used in the power supply circuit.

NOTICE! The outer ground connection must always be connected to the protective potential equalisation or a similar local potential equalisation.

The ground terminal is suitable for connecting fine-wire conductors up to 4 mm² or single-wire conductors up to 6 mm².

The earthing connection serves to discharge static electricity.



WARNING - DO NOT CONNECT OR DISCONNECT EQUIPMENT UNDER VOLTAGE

Fig. 11: Earthing connection

BA_EN_FT90 19/132

3.4.2 Devices only with switch outputs

3.4.2.1 Circuit

The device is connected as described below. The admissible load/impedance is stated in the technical data. The connection is performed using a prefabricated sensor connection cable (see the accessories). Alternatively, a prefabricated M12 connector can be used.

NOTICE! The protection class of the housing can be guaranteed only if an IP65 connecting plug is used.

Version dP/T/rH




Fig. 12: 3-channel version

Version T/rH





Fig. 13: 2-channel version

3.4.2.2 M12 connector 1: auxiliary energy and analogue output



Pin	Signal		Cable colour
1	Operating voltage	+ U _b	Brown
2	Unused		White
3	Operating voltage	- U _b	Blue
4	Unused		Black
5	Unused		Grey
Α	Coding		

Fig. 14: 5-pin M12 connector

3.4.2.3 M12 connector 2: switch outputs





Fig. 15: 8-pin M12 connector

Pin	Signal			Cable colour
1	Switch output 1	_	SP1	White
2	Switch output 1	\ <u></u>	SP1	Brown
3	Switch output 2		SP2	Green
4	Switch output 2		SP2	Yellow
5	Switch output 3	<u>,</u> —	SP3	Grey
6	Switch output 3	_	SP3	Pink
7	Switch output 4	<u>,</u> —	SP4	Blue
8	Switch output 4	_	SP4	Red
Α	Coding			

3.4.2.4 M12 connector 3: Sensor input

NOTICE! The operating voltage U+ is generated by FT90.



Pin	Signal		Cable colour
1	Operating voltage (internal)	GND	Brown
2	Operating voltage (internal)	U+	White
3	I2C bus	SDA	Blue
4	I2C bus	SCL	Black
Α	Coding		

Fig. 16: 4-pin M12 bush

BA_EN_FT90 21/132

3.4.3 Devices with switching and analog outputs

3.4.3.1 Circuit

The device is connected in a 3-wire circuit as described below. The admissible load/impedance is stated in the technical data. The connection is performed using a prefabricated sensor connection cable (see the accessories). Alternatively, a prefabricated M12 connector can be used.

NOTICE! The protection class of the housing can be guaranteed only if an IP65 connecting plug is used.

Version dP/T/rH




Fig. 17: 3-channel version

Version T/rH





Fig. 18: 2-channel version

3.4.3.2 M12 connector 1: auxiliary energy and analogue output



Pin	Signal		Cable colour
1	Operating voltage	+ U _b	Brown
2	Analog output 2	AOut2	White
3	Operating voltage	- U _b	Blue
4	Analog output 1	AOut1	Black
5	Analog output 3	AOut3	Grey
Α	Coding		

Fig. 19: 5-pin M12 connector

3.4.3.3 M12 connector 2: switch outputs





Fig. 20: 8-pin M12 connector

	•			
Pin	Signal			Cable colour
1	Switch output 1	\ _	SP1	White
2	Switch output 1	_	SP1	Brown
3	Switch output 2	_	SP2	Green
4	Switch output 2	_	SP2	Yellow
5	Switch output 3	\ _	SP3	Grey
6	Switch output 3	_	SP3	Pink
7	Switch output 4	_	SP4	Blue
8	Switch output 4	_	SP4	Red
Α	Coding			

3.4.3.4 M12 connector 3: Sensor input

NOTICE! The operating voltage U+ is generated by FT90.



Pin	Signal		Cable colour
1	Operating voltage (internal)	GND	Brown
2	Operating voltage (internal)	U+	White
3	I2C bus	SDA	Blue
4	I2C bus	SCL	Black
Α	Coding		

Fig. 21: 4-pin M12 bush

BA_EN_FT90 23/132

3.4.4 Devices with Modbus (without switch outputs)



⚠ DANGER

Auxiliary energy for ATEX devices

When selecting the power supply, bear in mind that it may be a potential ignition source.

Take suitable safety precautions to prevent this risk.




Fig. 22: Modbus replacement plate

The devices with a Modbus interface do not have analog and switch outputs. The replacement plate is equipped with a 5-pin M12 flange connector for the Modbus input and a 5-pin M12 flange socket for the Modbus output.

The FT90 can be connected to the Modbus RTU network as a slave. Up to 247 devices can be addressed in one line network.

NOTICE! Star-shaped networks are not allowed.




Fig. 23: Modbus RTU network

Communication is effected solely with the Modbus master. The connected slaves only react to direct commands from the master, so communication between the slaves is not possible.

To guarantee fault-free data transmission, we recommend terminating the end point of the Modbus RTU network with a 120 Ω resistor. This bus termination resistor is available as an accessory.

3.4.4.1 Connection to an existing Modbus RTU network

It can be connected to an existing Modbus network via a conventional T-piece (passive TAP).




Fig. 24: Modbus connection

3.4.4.2 Auxiliary energy supply

The following illustrations explain the principle of the power supply of the FT90 in the Modbus network. However the feeder nodes are not part of the delivery scope and need to be installed by the operator.




Fig. 25: Main supply

Please note that the M12 connectors are approved for max. 2A. This value can be exceeded with more than just 12 devices of the type FT90. In this case, an intermediate auxiliary energy feed should be provided at a suitable place.





Fig. 26: Intermediate supply

BA_EN_FT90 25/132


3.4.4.3 M12 plug 1: Modbus IN



PIN	Signal		Cable colour
1	Operating voltage	+U _b	Brown
2	Modbus	BUS-D1	White
3	Operating voltage	- U _b	Blue
4	Modbus	BUS-D0	Black
5	Modbus	BUS-R	Grey
Α	Coding		

Fig. 27: M12 plug 5-pin

3.4.4.4 M12 plug 2: Modbus OUT




PIN	Signal		Cable colour
1	Operating voltage	+U _b	Brown
2	Modbus	BUS-D1	White
3	Operating voltage	- U _b	Blue
4	Modbus	BUS-D0	Black
5	Modbus	BUS-R	Grey
Α	Coding		

Fig. 28: M12 bush 5-pin

3.4.4.5 M12 connector 3: Sensor input

NOTICE! The operating voltage U+ is generated by FT90.



Pin	Signal		Cable colour
1	Operating voltage (internal)	GND	Brown
2	Operating voltage (internal)	U+	White
3	I2C bus	SDA	Blue
4	I2C bus	SCL	Black
Α	Coding		

Fig. 29: 4-pin M12 bush

3.4.5 Devices with Modbus (and 4 switch outputs)



▲ DANGER

Auxiliary energy for ATEX devices

When selecting the power supply, bear in mind that it may be a potential ignition source.

Take suitable safety precautions to prevent this risk.

26/132 BA_EN_FT90




Fig. 30: Replacement plate Modbus with switch outputs

This version with a Modbus interface has 4 switch outputs. The replacement plate is equipped with a 5-pin M12 flange connector for the Modbus input and an 8-pin M12 flange connector for the switch outputs.

The FT90 can be connected to the Modbus RTU network as a slave. Up to 247 devices can be addressed in one line network. It is connected via a conventional T-piece (passive TAP).

NOTICE! Star-shaped networks are not allowed.




Fig. 31: Modbus RTU network

Communication takes place solely with the Modbus master. The connected slaves only react to direct commands from the master, so communication between the slaves is not possible.

To guarantee fault-free data transmission, we recommend terminating the end point of the Modbus RTU network with a 120 Ω resistor. This bus termination resistor is available as an accessory.

3.4.5.1 Connection to an existing Modbus RTU network

It can be connected to an existing Modbus network via a conventional T-piece (passive TAP).




Fig. 32: Modbus connection

3.4.5.2 Auxiliary energy supply

The following illustrations explain the principle of the power supply of the FT90 in the Modbus network. However the feeder nodes are not part of the delivery scope and need to be installed by the operator.

BA_EN_FT90 27/132




Fig. 33: Main supply

Please note that the M12 connectors are approved for max. 2A. This value can be exceeded with more than just 12 devices of the type FT90. In this case, an intermediate auxiliary energy feed should be provided at a suitable place.




Fig. 34: Intermediate supply

3.4.5.3 M12 connector 1: Modbus




Fig. 35: M12 plug 5-pin

PIN	Signal		Cable colour
1	Operating voltage	+U _b	Brown
2	Modbus	BUS-D1	White
3	Operating voltage	- U _b	Blue
4	Modbus	BUS-D0	Black
5	Modbus	BUS-R	Grey
Α	Coding		

3.4.5.4 M12 connector 2: Switch outputs





Fig. 36: 8-pin M12 connector

	•			
PIN	Signal			Cable colour
1	Switch output 1	<u>\</u> _	SP1	White
2	Switch output 1	_	SP1	Brown
3	Switch output 2	_	SP2	Green
4	Switch output 2	_	SP2	Yellow
5	Switch output 3	_	SP3	Grey
6	Switch output 3	_	SP3	Pink
7	Switch output 4	_	SP4	Blue
8	Switch output 4	_	SP4	red
Α	Coding			

3.4.5.5 M12 connector 3: Sensor input

NOTICE! The operating voltage U+ is generated by FT90.



Pin	Signal		Cable colour
1	Operating voltage (internal)	GND	Brown
2	Operating voltage (internal)	U+	White
3	I2C bus	SDA	Blue
4	I2C bus	SCL	Black
Α	Coding		

Fig. 37: 4-pin M12 bush

BA_EN_FT90 29/132

4 Start-up

4.1 Installation control

NOTICE! The check of the pressure lines is not necessary for devices without a pressure connection.

Before starting the measuring device:

- Check that the pressure lines are mounted correctly.
- 1. Is the measuring device undamaged?
- 2. Does the measuring device fulfil the requirements of the measuring point specification?
- 3. Are the pressure lines laid correctly?
- 4. Are the attachment screws tightened correctly?
- 5. Is the device adequately protected against precipitation and solar radiation?

Check that all electrical supply and measuring lines are installed correctly.

- 1. Are the connection lines undamaged?
- 2. Do the cables used fulfil the requirements?
- 3. Is there strain relief on the mounted cables?
- 4. Are the connection plugs mounted correctly?
- 5. Is the earthing connection connected correctly?

4.2 Switch on the measuring device

- ▷ The measuring device can be switched on after a successful installation check.
- 1. The start screen is now shown on the display.



Fig. 38: Start screen

→ After a successful start, the start screen switches to the measurement data display.

4.2.1 Measured value display

Depending on the unit model, there are different presentation variants for the measured value display.

4.2.1.1 2-channel version T/rH

Assignment:

Channel 1: Temperature Channel 2: Humidity

The display can be changed using the 'Meas.data display' menu. You can display the channels individually or at the same time. The bar graph display always shows both measuring channels.




Fig. 39: Measuring data display (2 channels)

BA_EN_FT90 31/132

4.2.1.2 3-channel version P/T/rH

Assignment:

Channel 1: Differential pressure

Channel 2: Temperature Channel 3: Humidity

The display can be changed using the 'Meas.data display' menu. The three channels can be displayed individually or at the same time. The bar graph display always shows all three measuring channels.




Fig. 40: Measuring data display (individual channels)




Fig. 41: Measuring data display (3 channels)

4.2.1.3 Back lighting

The LC display is equipped with RGB back lighting. This allows it to create various coloured backgrounds for the measuring data display.

Also, the so-called colour changes can be configured that serve to indicate when limits have been overstepped.

For more information, please go to menu display and/or colour change.

4.2.2 Keyboard

The basic functions of the keyboard are explained in this section. For more information about the operating concept, please see the section 'First steps'.




Fig. 42: Operating keys

•	Page down	Decrease value	
\$	Call up menu	Save value	Go back
_	Page up	Increase value	

The buttons are always pressed individually. Combinations such as pressing two buttons at the same time are not used.

A button can be actuated in two ways. Below, the adjacent symbols indicate the actuation type.

- 1. Pressing a button briefly triggers an immediate reaction.
- 2. Pressing a button for longer than 250 ms triggers a 'Repeat' reaction. Holding a button down, triggers a continuous sequence of 'Repeat' reactions. However, there is no acceleration.
- 3. Automatic stop at the menu item 'Back': Holding the button ▼ or ▲ down returns the user to the menu item 'Back' very quickly. The stop is automatic there.
- 4. Return to the operating display: Holding the button ♦ down takes the user from the menu item 'Back' to the operating screen.





BA_EN_FT90 33/132

4.3 Setup

The measuring device is completely configured in the factory before delivery. Nevertheless, all parameters can be adjusted directly on site using the keypad. Optionally, a configuration can also be created on the PC using the inTouch© software and transferred to the device via the USB interface.

4.3.1 Set menu language

Works setting: German or ordered national language

- > The menu language can be changed as follows.
- 1. You have the right to change the configuration.
- 2. Log in to the device and go to the menu Configuration and then to the menu Display.
- 3. There, open the menu Language and change the menu language.

4.3.2 Measuring point designation

- A designation for the measuring point can be filed to identify the device within a system.
- 1. You have the right to change the configuration.
- 2. Log in to the device and go to the menu Configuration and then to the menu Display.
- 3. Change the **Designation** parameter.

4.3.3 Configuration

The measuring device is delivered in the configuration stated in the Order code.

- Do you want to adjust the parameters on the device on site?
- 1. You have the right to change the configuration.
- 2. Log in to the device and call up the menu Configuration.
- 3. Carry out the required changes.
- The PC software inTouch[®] can be used for making more comprehensive changes to the configuration.
- 1. Carry out the changes on the PC using the inTouch software.
- 2. Transfer the configuration to the device via the USB interface.

4.4 Modbus RTU interface

The FT90 can also be supplied with a Modbus interface. This communication interface is set in the menu 'Modbus RTU [▶ 104]'.

4.5 IO-Link Interface

The FT90 can also be delivered with an IO-Link interface. Default settings for this interface are completed at the factory. The associated IODD and a description of the interface are available in the download area of the FISCHER website (www.fischermesstechnik.de).

5 Operation

5.1 First steps

5.1.1 Passwörter



NOTICE

Publicly accessible passwords

By publishing the passwords in these operating instructions, the parameterisation is accessible to everyone. Within the scope of security, it is absolutely necessary for the operator of the plant to issue new passwords for all user types.

The manufacturer is not liable for damages resulting from changes to a parameterisation.

The following passwords are assigned when the unit is delivered.

User	Password
User 1	000
User 2	000
User 3	000
Administrator	000

Users 1, 2, and 3 are disabled at delivery and must be explicitly enabled by the user. The administrator user can change all passwords in the respective menu Login > Manage users > User # > User # password.

If the same passwords are assigned, priority is given when logging in:

Administrator > User 1 > User 2 > User 3

Using the *Login > Reset passwords* function, the administrator user can reset all passwords to the factory setting 000.

See also

- Manage users [▶ 54]
- Reset passwords [▶ 57]

5.1.2 Operating modes

Operating mode

After activation, the device automatically starts. The device works according to its configuration.

Configuration mode

Pressing the button \Rightarrow takes the user from the operating mode to the configuration mode. The device is still operational and works according to its configuration. All parameter changes have a direct effect on how the device operates.

If the device is configured via the USB interface, operation is interrupted when transmission starts. Operation starts with the new configuration after transmission. The transfer lasts just a few milliseconds.

BA_EN_FT90 35/132

5.1.3 Menu tree

Login
Configuration
Info
Service
Fig. 43: Main menu

5.1.3.1 Login





Fig. 44: 'Login' submenu

5.1.3.2 Configuration



0

The Modbus menu only appears for devices with a Modbus RTU interface. For this re

Fig. 45: 'Configuration' submenu

5.1.3.2.1 Configuration -> Channel




Fig. 46: 'Configuration/Channel' submenu

BA_EN_FT90 37/132

Configuration channel1/mode = Linear




Fig. 47: Configuration/channel1/menu extension Linear

Configuration channel1/mode = Flow rate




Fig. 48: Configuration/channel1/menu expansion Flow rate

Configuration channel1/mode = Table




Fig. 49: Configuration/channel1/menu expansion Table

Configuration channel1/mode = Volume flow





Fig. 50: Configuration/channel1/menu expansion Volume flow

BA_EN_FT90 39/132

Configuration channel1/mode = Linear function



3-channel version

Fig. 51: Configuration/channel1/menu expansion Linear function

5.1.3.2.1.1 Configuration channel2/3 mode = Relative humidity





Fig. 52: Configuration/channel2(3)/menu expansion Relative humidity


2-channel version

5.1.3.2.1.2 Configuration channel 2/3 mode = Absolute humidity



2-channel version 3-channel version *Fig. 53:* Configuration/channel2(3)/menu expansion Absolute humidity

5.1.3.2.1.3 Configuration channel2/3 mode = Dew point



3-channel version

Fig. 54: Configuration/channel2(3)/menu expansion Dew point

2-channel version

BA_EN_FT90 41/132

3-channel version

5.1.3.2.1.4 Configuration channel 2/3 mode = Enthalpy




Fig. 55: Configuration/channel2(3) submenu/enthalpy menu expansion

5.1.3.2.2 Configuration -> Analog output

2-channel version




Fig. 56: Configuration/analogue output submenu

42/132 BA_EN_FT90

5.1.3.2.3 Configuration -> Switch output




Fig. 57: 'Configuration/Switch output' submenu

5.1.3.2.4 Configuration -> Display




Fig. 58: 'Configuration/Display' submenu

BA_EN_FT90 43/132

5.1.3.3 Info




Fig. 59: 'Info' submenu

3-channel version

5.1.3.4 Service




Fig. 60: 'Service' submenu

5.1.4 Navigation in the menu tree

Pressing the button ♦ takes the user from the 'Meas.data display' screen to the main menu.




Fig. 61: Accessing the main menu (level 0)

The menu has up to five levels. The levels are numbered from 0 to 4. Level 0 is the main menu. No distinction is made between menus and parameters in the display. However, a menu can be recognised by the indicator • .




Fig. 62: Moving down in the menu (level 0)

Buttons ▼ and ▲ are used to move the cursor through the menu. The button ⇒ opens the menu and the submenu of the next level appears on the display.

BA_EN_FT90 45/132




Fig. 63: Sideways in submenu (level 1)

To leave the menu, move the cursor to the 'Back' menu item. Press the ♦ button to return to the next highest level.




Fig. 64: Page down to exit

It is of course possible to move down the menu to the 'Back' menu item.

5.1.5 Path details

The path information appears in the first line of the display. For space reasons, the paths cannot be shown in full. The menu level is indicated by the number of backslash symbols ('\'). Where this is not possible, only the menu name is shown.

Path: \Configuration\Channel 2\Measurement C2\Measur.range C2 unit Level 0 Level 1 Level 2 Level 3



Fig. 65: Path

5.1.6 Input

The following softkeys are used whenever text or values are entered:

Edit

This softkey is used to switch into the editing window for entering text or values.

OK.

The input is completed with this softkey. The entered text or value is saved.

Cancel

The input is cancelled with this softkey. The originally saved text or value is retained

A softkey is pressed by first being selected with the buttons $\ lacktriangledown$ and $\ lacktriangledown$. The softkey is shown inverted. It is realised with the button $\ \diamondsuit$.

5.1.6.1 Text input

For example:

Path: \Quick access\Designation




Fig. 66: Action selection

Select the softkey Edit with the button ▼ or ▲. The selection is confirmed with the button ❖ . The following window opens for editing.

BA_EN_FT90 47/132




Fig. 67: Editing text

In this display, the cursor is controlled with the button \Rightarrow . The cursor can only be moved to the right. It is not possible to move back. If the cursor is moved past the edge, the display for selecting the action (see above) is displayed again.

Text is edited with the selection field in conjunction with the current cursor position. The button $\ \ \$ moves the list of characters $^{(2)}$ to the left and the button $\ \ \$ moves it to the right. Once the correct character is shown in the selection field, it can be accepted with the button $\ \$ at the cursor position. The cursor moves one character to the right and the next character position can be edited.

5.1.6.2 Value input

For example:

Path: \Configuration\Channel 1\Measurement C1\Meas.range C1 start




Fig. 68: Entry of numerical values, 1st position

Entry of digits one by one

Numerical values can be entered digit by digit from left to right. The buttons ▼ and ▲ are used to set the digits 0 to 9. The plus/minus sign changes automatically in accordance with the selected movement direction. The limit values determined from the device configuration cannot be undercut or exceeded. A set digit is accepted using the button ❖. The cursor then moves one position to the right. The movement direction of the cursor is defined and cannot be changed.



Fig. 69: Setting a figure

⁽²⁾ The list of characters comprises the characters of the character set Windows 1252 (Latin 1 and Latin 9)




Fig. 70: Entry of numerical values, 2nd position

A ♦ button repeat automatically returns the user to the action selection. Pressing the button again saves the value.

Number overflow

If the number 9 is set for one position and the button ▲ is pressed again, a number overflow occurs. In this example, the value is incremented from 29 to 30. Holding the button ▲ down (repeat) causes the value to increase gradually like a counter.




Fig. 71: Number overflow

The value is always incremented from the cursor position. If, for example, the cursor is on the first decimal place, the digit in that decimal place is incremented:

 $29.0 \rightarrow 29.1 \rightarrow 29.2 \dots$

However, if the cursor is in the final position, that digit is incremented as follows: $29.000 \rightarrow 29.001 \rightarrow 29.002$ up to the overflow $29.999 \rightarrow 30.000$ etc.

BA_EN_FT90 49/132

5.1.6.3 Selection of options

For example:

Path: \Configuration\Channel 2\Measurement C2\Meas.range C2 unit




Fig. 72: Entry of options

The cursor is moved with the buttons \blacktriangledown and \blacktriangle . Only one of the offered options can be selected. The button \diamondsuit is used to select the option marked by the cursor.

You can use the 'Back' exit button to return to the calling menu. The selected option is saved.

5.2 Main menu

Path: \
Level: 0

Pressing the \Rightarrow button takes the user from operating mode to configuration mode. The main menu is displayed. The bar graph display and display of the switch outputs still remain visible.

NOTICE! The device also remains operational during configuration. All parameter changes have a direct effect.




Fig. 73: Main menu

The indicator • shows that there is a submenu on the following level. The main menu comprises the following menus:

Menu name		Description
Login	١	In this menu, users can log in and out as well as manage passwords.
Configuration	•	The device is configured using this menu. There are up to four menu levels.
Info	•	This menu contains information about the hardware and software of the device and its configuration.
Service	•	The firmware of the device can be undated and parameters can be loaded and saved with this menu.
Back	ŧ.	This is the exit level of the main menu. It takes you 'Back' to the 'Meas.data display' screen.



Signposts [▶Page]

- Login [▶ 52]
- Configuration [▶ 58]
- Info
- Service

BA_EN_FT90 51/132

5.3 Login

Path: \Login Level: 1

Users that are not logged in only have access to the information menu. Users must log in to gain access to the configuration.



Fig. 74: Login

The login menu consists of the following parameters and submenus:

Menu name	Description
Log in / log out	Users can log in and out with this menu item.
Timeout	The timeout function is defined with this parameter.
Manager users ▶	This submenu is for managing users and passwords.
Reset passwords	This menu item is used to reset all passwords to 000 .
Back t	. This is the login menu exit point. It takes you back to the main menu.

5.3.1 Log in / log out

Path:\Login\Log in

Level: 2

Users log in by entering a numerical value. Once the correct password has been entered, the menus for which the user in question has access rights are unlocked.




Fig. 75: Log in

Users log out by selecting the menu item in question and confirming with the button ♦ . A key in the top right corner of the display indicates the logged-in user.




Fig. 76: Log out

BA_EN_FT90 53/132

5.3.2 Timeout

Path: \Login\Timeout

Level: 2

If the device is switched to configuration mode and no button is pressed, the device returns to the operating mode after the expiry of a defined time period. This time range is set with the parameter <code>Timeout</code>.

Values entered in minutes. The value range covers 0 ... 60 min. When the value 0 is entered, the timeout function is switched off.

After the set timeout time has expired, a logged in user is logged off whist the device switches to the operating mode.

If, however, the timeout function is deactivated, the user remains permanently logged in. Users must log off manually.

The key symbol should indicate this possibly undesirable status.

¹字

5.3.3 Manage users

Path: \Login\Manage users

Level: 2



Fig. 77: Manage users

The login menu consists of the following parameters and submenus:

Menu name		Description
User 1		This menu item is used to manage the
User 2		rights of the user in question.
User 3		
Administrator	•	The password for the administrator is defined in this menu.
Back	ŧ.	This is the exit point of the 'Manage users' menu. It takes you back to the main menu.

The menus for the users are identical, so only the menu for user 1 is described here as an example for all.

5.3.3.1 User 1

Path: \Login\Manage users\User 1

Level: 3



Fig. 78: User 1

Menu name		Description
User 1 enabled		The user can be enabled with this parameter.
User 1 password		The password for user 1 is defined with this parameter.
User 1 permissions	•	The permissions for user 1 are defined with this parameter.
Back	ŧ.	This is the exit point of the 'User 1' menu. It is used to return to the 'Manage users' menu.

The parameter User 1 enabled activates user 1:

- □ User disabled
- User enabled

The password for the user is assigned with the parameter <code>User 1</code> <code>password</code> . The password 000 is assigned with the default setting. Only numerical passwords from 000 to 999 can be used.

BA_EN_FT90 55/132

5.3.3.1.1 User 1 permissions

Path: \Login\Manage users\User 1\User 1 permissions

Level: 4




Fig. 79: User 1 permissions

Menu name		Description
View configuration		This parameter assigns read permission.
Edit configuration		This parameter assigns read and write permission.
Update firmware		This parameter assigns permission to perform an update.
Manage users		This parameter assigns user management permission.
Back	ŧ.	This is the exit point of the 'User 1 permissions' menu. It takes you back to the 'User 1' menu.



The parameter 'View configuration' is used to define whether the user may read the configuration. The activation of read permission is indicated by the crossed-out pencil symbol. This indicates that the user does not have write permission.



Read and write permission is assigned with the parameter 'Edit configuration'. This permission allows the user to change the configuration. Access to the service menu is allowed. However, the user does not have permission to manage users or perform a firmware update.

Permission to update the firmware is assigned with the parameter 'Update firmware'.

Permission to change user permissions is assigned with the parameter 'Manage users'.

A user with all permissions does **not** have access to the administrator menu and is not allowed to reset the passwords to the factory settings.

5.3.3.2 Administrator

Path: \Login\Manage users\Administrator

Level: 3



Fig. 80: Administrator

The password for the administrator is assigned with the parameter 'Admin. password'. The administrator has unlimited access to all menus and parameters.

5.3.4 Reset passwords

Path: \Login\Reset passwords

Level: 2




Fig. 81: Reset passwords

All passwords are set to the default value 000. Only the administrator can carry out this action. Set permissions of users are retained.

BA_EN_FT90 57/132

5.4 Configuration

The device can also be configured with the **inTouch**® software on a PC. The finished parameter set is then transferred to the FT90 via the USB interface.



MARNING

Configuration in potentially explosive areas

The housing may not be opened within the ATEX area. This means that configuration and firmware updates via the USB interface are only possible outside the potentially explosive area.

Path: \Configuration

Level: 1



Fig. 82: Configuration

The parameters and menus are described for a device with three channels. The displays and descriptions may vary in the case of a device with two channels.

Menu name		Description
Input	•	This menu can be used to configure the input.
Channel 1	•	This menu is used to configure the 1st measuring channel.
Channel 2	•	This menu is used to configure the 2nd measuring channel.
Channel 3	•	This menu is used to configure the 3rd measuring channel.
Analogue output	•	The analogue outputs are configured with this menu.
Switch output	•	The switch outputs are configured with this menu.
Display	F	This display is configured with this menu.
Modbus RTU	٠	This menu is available for Modbus devices only. It enables the configuration of the interface.
Back	ŧ.	This is the exit point of the configuration menu. It takes you 'Back' to the main menu.



Signpost [▶Page]

- Input [▶ 60]
- Channel 1 [▶ 62]
- Channel 2 [▶ 85]
- Channel 3 [▶ 91]
- Analogue output [> 93]
- Switch output [▶ 96]
- Display [▶ 99]
- Modbus RTU [▶ 104]

BA_EN_FT90 59/132

5.4.1 Input

The introduction of software 1.41 includes the replacement of the FF90 by the FF12 sensor, which will also be delivered as a spare part in the future. To ensure the compatibility of older devices during a firmware update, there is now the option of choosing between the two sensor types.

Path: \Configuration\Input

Level: 2



Fig. 83: Input

Menu name		Description
Sensor type	•	The sensor type can be selected in this menu.
Back	ŧ.	This is the exit point of the channel 1 menu. It takes you 'Back' to the configuration menu.

5.4.1.1 Sensor type

Path: \Configuration\Input\Sensor type

Level: 3




Fig. 84: Sensor type

Menu name		Description
Standard	•	Automatic detection of the connected sensor type.
FF90	0	Manual selection of the old sensor type.
FF12	0	Manual selection of the successor type (from firmware 1.41).
Back	ŧ.	This is the exit point of the channel 1 menu. It takes you 'Back' to the input menu.




NOTICE

Automatic detection

If the **Standard** option is selected, sensors of type FF90 and FF12 are automatically recognised after installation (replacement). If the sensor is not recognised, select the sensor type manually.

- 1. All FF12 sensors are labelled on the cap.
- 2. This labelling is missing on the FF90 sensors.



BA_EN_FT90 61/132

5.4.2 Channel 1

The parameterisation of the channels is largely the same for all versions. However, the following should be noted:

2 channel version		3 channel v	3 channel version		
Channel 1	Temperature	Channel 1	Differential pressure		
Channel 2	Humidity	Channel 2	Temperature		
		Channel 3	Humidity		

5.4.2.1 2 channel version [temperature]

Path: \Configuration \ Channel 1

Level: 2




Fig. 85: Channel 1

Menu name		Description
Measurement C1	١	Parametrise the input of the measuring channel in this menu.
Number format C1	١	The decimal places for the measured value display of the measuring channel are set in this menu.
Colour change C1	•	Parameterise the colour changes for the measuring channel in this menu.
Back	ŧ.	This is the exit point of the channel 1 menu. It takes you 'Back' to the configuration menu.



Signpost [▶Page]

- Measurement C1 [▶ 65]
- Number format C1 [▶ 79]
- Colour change C1 [▶ 80]

5.4.2.2 3 channel version [differential pressure]

Path: \Configuration \ Channel 1

Level: 2




Fig. 86: Channel 1

Menu name		Description
Mode C1	•	This menu can be used to select defined functions for the measuring channel.
Measurement C1	•	The input of the measuring channel is parameterised in this menu.

Menu extension

F	This menu is hidden depending on the selected mode.
•	The decimal places for the measured value display of the measuring channel are set in this menu.
•	The colour changes for the measuring channel are parameterised in this menu.
ŧ.	This is the exit point of the channel 1 menu. It takes you 'Back' to the configuration menu.
	Þ



Signpost [▶Page]

- Mode C1 [▶ 64]
- Measurement C1 [▶ 65]
- Characteristic curve C1 (menu extension) [▶ 72]
- Number format C1 [▶ 79]
- Colour change C1 [▶ 80]

BA_EN_FT90 63/132

5.4.2.2.1 Mode C1

Path: \Configuration\Channel 1\Mode C1

Level: 3




Fig. 87: Mode C1

In this menu, different operating modes can be selected for the 1st measuring channel (C1). The currently selected mode is shown by the option field.

Parameter value	Description
Linear	Linear input characteristic
Flow rate	Flow rate measurements on a measuring orifice
Table	Fill level measurements on tanks
Volume flow	Volume flow measurements in ventilation systems
Linear function	Mathematic function $f(x) = mx + b$
Back t .	This is the menu exit point. It takes you back to the 'Channel 1' menu.

Each of these operating modes requires a different configuration of the characteristic. Consequently, the calling menu after the exit has the menu expansion 'Characteristic C1', which enables the configuration of the characteristic for the selected mode.

The 'Linear' operating mode is an exception. There is no menu expansion because configuration takes place only in the menu 'Measurement C1'.

See also

Characteristic curve C1 (menu expansion) [▶ 72]

5.4.2.2.2 Measurement C1

Path: \Configuration\Channel 1\Measurement C1

Level: 3




Fig. 88: Measurement C1

In this menu, the linear starting range is configured independent of the set operating mode.

Menu name		Description
Meas.range C1 unit	•	In this menu, the measurement unit of the physical variable that is to be measured must be defined.
Meas.range C1 start		The start of the measuring range is defined with this parameter.
Meas.range C1 end		The end of the measuring range is defined with this parameter.
Damping C1		The damping parameter serves to dampen the display.
Offset C1		The characteristic is displaced with the parameter offset.
Zero-pt. window C1		Only for devices with differential pressure measurement.
		The zero point window parameter defines a range around zero in which the display value is set to zero.
Limits		This property determines whether or not the set measuring range limits also act on the meas.data display.
Back	ŧ.	This represents the output (exit) of the menu. Press 'back' to return to the channel 1 menu



NOTICE

Unit of the measuring range

The above menu is structured in the same way for channels 2 and 3. For the measured variable 'Humidity', however, the menu for the unit is omitted, as the humidity is measured in the unit [%RH] and therefore the selection of a unit is omitted.

BA_EN_FT90 65/132

5.4.2.2.1 Measuring range C1 unit

Differential pressure

Path: \Configuration\Channel 1\Measurement C1\Meas.range C1 unit Level: 4



Fig. 89: Measuring range C1 unit

Implemented pressure units:

Unit		Description
bar	bar	Metric and SI units
mbar	milli bar	
Pa	Pascal	
kPa	kilo Pascal	
MPa	Mega Pascal	
psi	pound-force per square inch	Anglo-American units (Imperial
inH ₂ O	inch water column	Units)
mmH ₂ O	mm Water column	Historical units
mmHg	mm Mercury column	

If the pressure unit changes, all parameters are automatically converted.

Temperature

Path: \Configuration\Channel 1\Measurement C1\Meas.range C1 unit Level: 4




Fig. 90: Measuring range C1 unit

Implemented temperature units:

Unit		Description
°C	Celsius	Metric and SI units
°F	Fahrenheit	Anglo-American units (imperial units)

Humidity

The unit for humidity is fixed as $\mbox{\em \$rH}$.

5.4.2.2.2 Measuring range C1 start

Path: \Configuration\Channel 1\Measurement C1\Measur. range C1 start Level:4



Fig. 91: Measuring range C1 start

The start value of the measuring range is entered here. This input acts directly on the output signal. The display is not directly affected.

The unit, value range, and value range limits are displayed automatically.

In the factory configuration, a basic measuring range is defined for each device. This basic measuring range is defined by the order code and is stated as the measuring range on the type plate.

The parameters 'Meas.range C1 start' and 'Meas.range C1 end' are for configuring the input range of measuring channel C1.

Spread (turn down)

The characteristic can be spread within the basic measuring range. The spread is the ratio between the basic measuring range and the set measuring range and may be a maximum of 4:1. This means that the difference between the two values 'Meas.range C1 start' and 'Meas.range C1 end' must be at least 25% of the basic measuring range.




Fig. 92: Turn down

The spread of the characteristic only acts directly on the output signal. The activation of the parameter 'Limit' limits the display area to the set measuring range, too.

Characteristic slope

If 'Meas.range C1 start' < 'Meas.range C1 end', this gives a rising characteristic. The output signal increases with increasing pressure.

If 'Meas.range C1 start' > 'Meas.range C1 end', this gives a falling characteristic. The output signal drops with increasing pressure.

BA_EN_FT90 67/132

5.4.2.2.3 Measuring range C1 end

Path: \Configuration\Channel 1\Measurement C1\Meas.range C1 end Level: 4



Fig. 93: Measuring range C1 end

At this point, the end value of the measuring range is entered. The value range and its limits are displayed automatically.

5.4.2.2.2.4 Damping C1

Path: \Configuration\Channel 1\Measurement C1\Damping C1

Level: 4



Fig. 94: Damping C1

If there are unsteady measurement readings during operation, you can use the parameter $Damping\ C1$ to stabilise the reading.

The value range is from 0 s to 30 s.

The parameter functions like a capillary throttle. Please note that the damping only affects the signal input. The measuring cell itself is not uninfluenced. The parameter value states the time period until the amplitude reaches 90 %. A value of 0s means that no damping is carried out.

5.4.2.2.2.5 Offset C1

Path: \Configuration\Channel 1\Measurement C1\Offset C1 Level: 4




Fig. 95: Offset C1

If the measuring data display in the zero-point shows a different value, this can be corrected with the parameter $\mathsf{Offset}\ \mathsf{C1}$.

The value range is one third of the basic measuring range.

The current measurement is shown at the bottom right. During the input, the set offset parameters act immediately on the measured value. Please note that this zero-point window and the damping are not active during the offset setting.




Fig. 96: Offset error

The parameter causes a shift of the entire characteristic toward the ideal characteristic.

BA_EN_FT90 69/132

5.4.2.2.2.6 Zero-point window C1

NOTICE! This menu is only available for devices with differential pressure channel.

Path: \Configuration\Channel 1\Measurement C1\Zero-pt. window C1 Level: 4



Fig. 97: Zero-point window C1

Unsteady readings are not usually a problem during normal operating mode, but this is not true for the idle state, if a measured value of zero is expected. The parameter $Zero-pt.\ window\ C1$ is designed to solve this.

The value range is one third of the basic measuring range.




Fig. 98: Zero-point window

The parameter value (x) defines a range around zero, the so-called zero-point window. All measured values within this window are displayed as a zero value. The reading will only no longer show zero, if the pressure lies outside the set window.

In this area, approximation is linear up to twice the parameter value (2x). Only when twice the pressure is reached for the zero-point window, the measured value and the reading match again. This avoids jumps in the display.

5.4.2.2.2.7 Limits

Path: \Configuration\Channel 1\Measurement C1

Level: 3




Fig. 99: Limit C1

With this property, the measuring data display can be limited to the Meas.range C1 start and Meas.range C1 end measuring range defined with the parameters. The button ⇒ is used to activate and deactivate.

BA_EN_FT90 71/132

5.4.2.2.3 Characteristic curve C1 (menu expansion)

NOTICE! This menu is available only for devices with a differential pressure channel.

The menu changes depending on the set operating mode of the measuring channel.

The menu expansion is not present for devices for which the parameter 'Mode' has been set to the value 'Linear'.

5.4.2.2.3.1 Characteristic C1 (flow rate)

Path: \Configuration\Channel 1\Characteristic C1 Level: 3




Fig. 100: Characteristic C1 (flow rate)

Menu name		Description
Displ.range C1 unit		This parameter is used to define the flow rate unit. It must have a length of at least 5 characters.
Displ.range C1 start		The start of the display range is defined with this parameter.
Displ.range C1 end		The end of the display range is defined with this parameter.
Back 1	ŧ.	This represents the output (exit) of the menu. Press 'back' to return to the Channel 1 menu.

This function allow the flow rate to be measured by means of an effective pressure procedure on a measuring panel. The differential pressure is a measure for the flow rate:

$$q = \sqrt{\Delta p}$$
 q : Flow rate
$$\Delta p$$
: Differential pressure

The root extracted input signal is shown as a signal from 0 ... 100 %. The display value can be furnished with a different unit with the parameter <code>Displ.rangeC1</code> unit ´. The display range can be scaled to this unit with the parameters <code>Displ.C1</code> start and <code>Displ.rangeC1</code> end .

5.4.2.2.3.2 Characteristic C1 (Table)

Path: \Configuration\Channel 1\Characteristic C1

Level: 3



Fig. 101: Characteristic C1 (table)

Menu name		Description
Displ.range C1 unit		A unit for the display value is defined with this parameter. It must have a length of at least 5 characters.
Table C1		The table is defined in this menu.
Back	ŧ.	This represents the output (exit) of the menu. It is used to return to the Channel 1 menu.

The table function can be used to correct the input characteristic of the sensor at any point. The changes impact on the display value and the output signal.

5.4.2.2.3.2.1 Table C1

Path: \Configuration\Channel 1\Characteristic C1\Table C1

Level: 4




Fig. 102: Table C1

Menu name	Description	
No. Value pairs	This parameter is used to define the number of value pairs.	
	Value range: 2 30	
Input value 1	Value pair 1	
Display value 1		
Input value 2	Value pair 2	
Display value 2		
:		
Input value 30	Value pair 30	
Display value 30		
Back € .	This is the exit point of the channel 1 menu. It takes you 'Back' to the Characteristic C1 menu.	

BA_EN_FT90 73/132

Each support point is stated by a value pair comprising the $Input value \times and Display value \times$. The index \times states the number of the value pair. At least two value pairs always need to be stated. The maximum number of value pairs is 30.

The first value pair is assigned to the start of the measuring range and the last value pair to the end of the measuring range. There is a linear interpolation of the characteristic between two values. The input values must either be continuously rising or falling. This is not mandatory for the assigned display values.

The table should have 7 value pairs ⁽³⁾. Of the input signal, the range 20 ... 80 Pa should be used. The basic measuring range is 0 ... 100 Pa. The display should display in the start of the measuring range 20 Pa and at the end of the measuring range 80 Pa.

Basic measuring range 0...100 Pa Measuring range 20 ... 80 Pa Display range 10 ... 70 Pa Output signal 0...20 mA

The value point 5 should be displayed so that the output delivers 12 mA. The following values are then entered in the menu $Table\ C1$:

Input	E1	02	О3	04	O5	O5	O6	07
Value [Pa]	20	30	40	50	60	56	70	80
Display	A 1	A2	A 3	A4	A5	A5	A6	A7
Value [Pa]	10	20	30	40	50	46	60	70
Output [mA]	0	3.33	6.66	10	13.33	12	16.66	20




Fig. 103: Table function

For example:

⁽³⁾input values are abbreviated with E1...E7 and display values with A1...A7

5.4.2.2.3.3 Characteristic C1 (volume flow)

Path: \Configuration\Channel 1\Characteristic C1

Level: 3




Fig. 104: Characteristic C1 (volume flow)

Menu name		Description
Displ.range C1 unit	١	This parameter can be used to set a unit for the display.
Displ.range C1 end		The end of the display range is defined with this parameter.
K factor C1		This parameter is used to enter the specific calibration factor for the panel type.
Air density C1		This parameter can be used to enter the air density at operating temperature.
Formula C1	F	The calculation formula is selected in this menu.
Back	ŧ.	This represents the output (exit) of the menu. It is used to return to the Channel 1 menu.

This function allow the volume flow to be measured by means of an effective pressure procedure.

Fig. 105: Volume flow basic formula

The ventilator is equipped with a measuring device to measure the volume flow. Each manufacturer states a K factor for his ventilator. This is filed with the parameter K factor C1.

The calculation formula of the manufacturer can deviate from the basic formula. Therefore the manufacturer of the ventilator used in the menu Formula C1 must be selected.

Due to the fact that the volume of a gas changes with the pressure and the temperature, the air pressure at operating temperature is taken into account in the calculation. The value can be entered with the parameter $\operatorname{\fraceharmone{Air}}$ density $\operatorname{\fraceharmone{C1}}$. As standard, the density is preset with 1.2040 kg/m³. (4)

BA_EN_FT90 75/132

 $^{^{(4)}}$ This value corresponds to the air density at 20 $^{\circ}$ C as sea level at an atmospheric pressure of 1013.25 hPa and dry air

5.4.2.2.3.3.1 Display range C1 unit

Path: \Configuration\Channel 1\Characteristic C1\Displ.range C1 unit

Level: 4



Fig. 106: Display range C1 unit

The following units are available for selection:

m³/h	Cubic metre per hour	Default value
l/s	Litre per second	
cfm	Cubic feet per minute	

5.4.2.2.3.3.2 Formula C1

Path: \Configuration\Channel 1\Characteristic C1\Formula C1

Level: 4



Fig. 107: Formula C1

The following table lists the formulas specified by the respective manufacturer for calculating the volume flow.

Standard EBM Pabst Goal Abegg SIEGLE+EPPLE	$q = k \cdot \sqrt{\Delta p}$
Comefri Nicotra Gebhardt Rosenberg	$q = k \cdot \sqrt{\frac{2}{\rho} \cdot \Delta p}$
Fläkt Woods	$q = \frac{1}{k} \cdot \sqrt{\Delta p}$

Fig. 108: Volumetric flow measurement Manufacturer's formulas

Volume flow measurement at the inlet cone




Fig. 109: Volume flow measurement

Fans are usually equipped with an inlet cone. The volume flow measurement consists of one or more measuring points in the inlet cone and one measuring point in the suction chamber of the ventilation unit. The differential pressure between the measuring points is used to calculate the volume flow.

The basic formula given applies to a frictionless and loss-free flow with constant density. In reality, therefore, a correction value caused by the design and other factors must be taken into account.

The fan manufacturers have determined the correction value for each inlet nozzle. In general, these values are called calibration factor or K-factor and can be found in the data sheet or operating instructions of the volume flow measuring device.

BA_EN_FT90 77/132

5.4.2.2.3.4 Characteristic C1 (linear function)

Path: \Configuration\Channel 1\Characteristic C1

Level: 3



Fig. 110: Characteristic curve C1 (linear function)

Menu name	Description
Displ.range C1 unit	This parameter defines the unit of the flow measurement. A maximum of 5 characters can be used.
Displ.range C1 start	This parameter defines the beginning of the display range.
Displ.range C1 end	This parameter defines the end of the display range.
Slope C1	This parameter determines the slope (m) of the linear characteristic.
Offset C1	This parameter defines the axis section (b) of the linear characteristic.
Back t	This represents the output (exit) of the menu. This takes you back to the Channel 1 menu.

With this menu, the output characteristic can be parameterized as a linear function.




Fig. 111: Linear function

5.4.2.2.4 Number format C1

Path: \Configuration\Channel 1\Number format C1

Level: 3




Fig. 112: Number format C1

The number of decimal places can be determined with this menu. All theoretically possible variants are made available for selection.

The decimal places are limited by the measuring range. There are 8 characters available with signs, decimal points and number value. The measuring data display can have less decimal points than set in the number format.

For example: Set number format: ±123.456

Current measuring value: -1234.567
Displayed measuring value: -1234.57

Only two decimal points are shown, as otherwise the maximum number of 8 characters would be exceeded. The last decimal place is rounded.

BA_EN_FT90 79/132

5.4.2.2.5 Colour change C1

Path: \Configuration\Channel 1\Colour change C1

Level: 3



Fig. 113: Colour change C1

This menu is used to set the switch threshold for the colour change of the back lighting. A pre-requisite for the efficiency of the switch thresholds is the activation of the colour change in the menu LCD colour and its assignment to measuring channel K1 in the menu Col.ch. assignment.

Menu name		Description
Col.ch. C1 red-grn		Switching thresholds for the named
Col.ch. C1 grn-red		colour change
Col.ch. C1 red-ylw		
Col.eh. C1 ylw-grn		
Col.ch. C1 grn-ylw		
Col.ch. C1 ylw-red		
Col.eh. C1 hyst		This parameter can be used to set an hysteresis for all switch thresholds.
Col.ch. C1 delay on		This parameter can be used to set an activation delay for all switch thresholds.
Col.ch. C1 delay off		This parameter can be used to set a deactivation hysteresis for all switch thresholds.
Back	ŧ.	This represents the output (exit) of the menu. Press 'back' to return to the Channel 1 menu.

There are precisely two types of colour change that can be set in the menu LCD colour. Depending on this, certain thresholds are ignored. So, for instance, the switching threshold Col.ch. C1 ylw-grn is not relevant for the colour change type red/green.

By means of colour changes, it is possible to signalise certain operating states by the colour of the back lighting.

5.4.2.2.5.1 Colour change C1 type: red/green

The following switching thresholds are relevant for this colour change:





Fig. 114: Colour change red/green



For example:

Input of the threshold red/green

Path: \Configuration\Channel 1\Colour change C1\Col.ch. C1 red-grn Level: 4



Fig. 115: Colour change C1 red-green

The other switch thresholds are entered in the same way.

BA_EN_FT90 81/132

5.4.2.2.5.2 Colour-change C1 type: red/yellow/green

The following switching thresholds are relevant for this colour change:




Fig. 116: Colour change red/yellow/green

MS	Meas.range C1 start	See menu Measurement C1 : [▶ 65]
S1	Col.ch. C1 ned-ylw	
S2	Col.ch.C1 ylw—grn	
S3	Col.ch.C1 grn/ylw	
S4	Col.ch.C1 ylw/red	
ME	Meass.range C1 end	See menu Measurement C1 : [> 65]

For example:

Channel 1: Basic measuring range: 0 ... 100 Pa

The measuring range is defined as 10 ... 90 Pa. The green range should be 0 ... 60 Pa. Then the critical range (yellow) up to 70 Pa starts. This is where the red range that ranges up to the measuring range end at 90 Pa starts. The lower colour changes red-yellow and yellow-green are switched off.




Fig. 117: Example colour-change red/yellow/green

MS	Meas.range C1 start	10 Pa	
S1	Col.ch. C1 red-ylw	5 Pa	< MS
S2	Col.ch.C1 ylw-grn	5 Pa	< MS
S 3	Col.ch.C1 grn/ylw	60 Pa	
S4	Col.ch.C1 ylw/red	70 Pa	
ME	Ms.range C1 end	90 Pa	

The lower colour changes S1 and S2 are 'switched off' by placing thresholds outside the measuring range. If the threshold values were to be laid precisely at the start of the measuring range, the display would shine red in the zero-point,

Red > Yellow > Green

The cause for this lies in the priority of the colours. The red colour has priority over the yellow colour and this has priority over the green colour.

5.4.2.2.5.3 Colour change C1 hysteresis

Path: \Configuration\Channel 1\Colour change C1\Col.ch. C1 hyst. Level: 4




Fig. 118: Colour change C1 hyst.


This parameter can be used to define an hysteresis for the switch thresholds of the colour change. The set hysteresis applies to all switch thresholds at the same time. The input is a pressure value in the current unit. The allowed value range is stated automatically.

Functional principle:

The colour symbolises the following risk levels:

Colour	Risk level	Operating mode
Green	0	Normal
yellow	1	Warning
rot	2	Danger

The following colour change red/yellow/green is examined as an example for all colour changes. There are a total of four switch thresholds (S1...S4) in which a colour change is realised. This leads to the following image without hysteresis.



Risk level Switching thresholds

Fig. 119: Colour change (without hysteresis)

The parameter Col.ch. C1 hyst. defines a distance to the switch threshold. The colour change with hysteresis is then realised as follows:

(i) Lower switching thresholds S1 and S2

In case of a colour change from a higher to a lower risk level, the hysteresis acts with an increasing signal.




Fig. 120: Example: Hysteresis S1

(ii) Upper switching thresholds S3 and S4

In case of a colour change from a lower to a higher risk level, the hysteresis acts with an decreasing signal.




Fig. 121: Example: Hysteresis S4

BA_EN_FT90 83/132

5.4.2.2.5.4 Colour change C1 delay on

Path: \Configuration\Channel 1\Colour change C1\Col.ch. C1 delay on Level 4:




Fig. 122: Colour change C1 delay on

The activation delay acts when changing from a lower risk level to a higher risk level.

5.4.2.2.5.5 Colour change C1 delay off

Path: \Configuration\Channel 1\Colour change C1\Col.ch. C1 delay off Level: 4




Fig. 123: Colour change C1 delay off

The deactivation delay acts when changing from a higher risk level to a lower risk level.

This results in the following connection between the delay and the colour change:




Fig. 124: Colour change delay

5.4.3 Channel 2

The parameterisation of the channels is largely the same for all versions. However, the following should be noted:

2 channel v	ersion	3 channel ve	3 channel version	
Channel 1	Temperature	Channel 1	Differential pressure	
Channel 2	Humidity	Channel 2	Temperature	
		Channel 3	Humidity	

5.4.3.1 2 channel version [humidity]

Path: \Configuration \ Channel 2

Level: 2




Fig. 125: Channel 2

Menu name		Description
Mode C2	•	The physical measured variable for the humidity sensor is defined in this menu.
Measurement C2	•	The input of the measuring channel is parameterised in this menu.
Characteristic C2	•	This menu is hidden depending on the selected mode.
Number format C2	•	The decimal places for the measured value display of the measuring channel are set in this menu.
Colour change C2	•	The colour changes for the measuring channel are parameterised in this menu.

This represents the exit of the menu. This takes you 'Back' to the paramet-

erisation menu.

Menu extension



Signpost [▶Page]

Back

- Modus C2 [▶ 86]
- Characteristic curve C2 [> 87]

The further explanations of the menus are identical to those for channel 1.

- Measurement C2 [▶ 65]
- Number format C2 [▶ 79]
- Colour change C2 [▶ 80]

BA_EN_FT90 85/132

5.4.3.1.1 Mode C2

Path: \Configuration\Channel 2\Mode C2

Level: 3



Fig. 126: Mode C2

Parameter value		Description
Relative humidity	•	This option measures the relative humidity indicated in [%RH].
		The relative humidity depends on the temperature and pressure of the thermodynamic system.
Absolute humidity	0	This option calculates the absolute humidity from the ambient temperature and the relative humidity. It is indicated in [g/m³].
		Exceeding the absolute humidity leads to condensation.
Dew point O	This option calculates the dew point temperature indicated in [°C] or [°F].	
		The dew point is the maximum water vapour content of the air.
Enthalpy O	This option calculates the specific enthalpy . It states the enthalpy per kilogram and is indicated in [kJ/kg].	
		Enthalpy is a measure of the energy of a thermodynamic system.
Back	ŧ.	This is the menu exit point. It takes you 'Back' to the Channel 2 menu.

5.4.3.1.2 Characteristic C2 (menu expansion)

5.4.3.1.2.1 Characteristic C2 (absolute humidity)

Path: \Configuration\Channel 2\Characteristic C2

Level: 3



Fig. 127: Characteristic C2 (absolute humidity)

Menu name		Description
Displ.range C2 start		The start of the display range is defined with this parameter.
Displ.range C2 end		The end of the display range is defined with this parameter.
Back ·	ŧ.	This is the menu exit point. Press 'Back' to return to the Channel 2 menu.

BA_EN_FT90 87/132

5.4.3.1.2.2 Characteristic C2 (dew point)

Path: \Configuration\Channel 2\Characteristic C2

Level: 3




Fig. 128: Characteristic C2 (dew point)

Menu name		Description
Displ.range C2 unit	١	This menu is used to define the display range unit.
Displ.range C1 start		The start of the display range is defined with this parameter.
Displ.range C1 end		The end of the display range is defined with this parameter.
Back	ŧ.	This is the menu exit point. Press 'Back' to return to the Channel 2 menu.

5.4.3.1.2.2.1 Displ.range C2 unit

Path: \Configuration\Channel 2\Characteristic C2\Displ.range C2 unit

Level: 3



Fig. 129: Display range C2 unit

Menu name		Description
°C	◉	Default value
°F	0	
Back	ŧ.	This is the menu exit point. Press 'back' to return to the Characteristic C2 menu.

5.4.3.1.2.3 Characteristic C2 (enthalpy)

Path: \Configuration\Channel 2\Characteristic C2

Level: 3



Fig. 130: Characteristic C2 (enthalpy)

Menu name	Description
Displ.range C2 start	The start of the display range is defined with this parameter.
Displ.range C2 end	The end of the display range is defined with this parameter.
Back t	This is the menu exit point. Press 'Back' to return to the Channel 2 menu.

BA_EN_FT90 89/132

5.4.3.2 3 channel version [temperature]

Path: \Configuration\Channel 2

Level: 2




Fig. 131: Channel 2

Menu name		Description
Measurement K2	١	The input of the measuring channel is parameterised in this menu.
Number format K2	•	The decimal places for the measured value display of the measuring channel are set in this menu.
Colour change K2	•	The colour changes for the measuring channel are parameterised in this menu.
Back	ŧ.	This represents the exit of the menu. This takes you 'Back' to the parameterisation menu.



Signpost [▶Page]

The explanations for the menus are identical to those for channel 1.

- Measurement K2 [▶ 65]
- Number format K2 [▶ 79]
- Colour change K2 [> 80]

5.4.4 Channel 3

The configuration of the channels is largely the same for all versions. However, note the following:

2-channel v	ersion	3-channel v	ersion
Channel 1	Temperature	Channel 1	Differential pressure
Channel 2	Humidity	Channel 2	Temperature
		Channel 3	Humidity

5.4.4.1 3 channel version [Humidity]

Path: \Configuration\Channel 3

Level: 2





Fig. 132: Channel 3

Menu name		Description
Mode K3		The physical measured variable for the humidity sensor is defined in this menu.
Measurement K3	•	The input of the measuring channel is parameterised in this menu.

Menu extension





Signpost [▶Page]

- Mode K3 [▶ 92]
- Characteristic curve K3 [▶ 92]

The explanations for the menus are identical to those for channel 1.

- Measurement K3 [▶ 65]
- Number format K3 [▶ 79]
- Colour change K3 [▶ 80]

BA_EN_FT90 91/132

5.4.4.1.1 Mode C3

Path: \Configuration\Channel 3\Mode C3

Level: 3



Fig. 133: Mode C3

Parameter value		Description
Relative humidity	•	This option measures the relative humidity indicated in [%RH].
		The relative humidity depends on the temperature and pressure of the thermodynamic system.
Absolute humidity	0	This option calculates the absolute humidity from the ambient temperature and the relative humidity. It is indicated in [g/m³].
		Exceeding the absolute humidity leads to condensation.
Dew point O	This option calculates the dew point temperature indicated in [°C].	
		The dew point is the maximum water vapour content of the air.
Enthalpy O	This option calculates the specific enthalpy . It states the enthalpy per kilogram and is indicated in [kJ/kg].	
		Enthalpy is a measure of the energy of a thermodynamic system.
Back	ŧ.	This is the menu exit point. It takes you 'Back' to the Channel 3 menu.

5.4.4.1.2 Characteristic C3 menu expansion

The menu expansion for characteristic C3 depends on the selected mode C3. Just like for channel 2, the display ranges are defined for various physical measured variables of humidity.

See also

Characteristic C2 (menu expansion) [▶ 87]

5.4.5 Analog output

The number of analog outputs depends on the version.

2-channel version	2 analog outputs
3-channel version	3 analog outputs

Path: \Configuration\Analog output

Level: 2




Fig. 134: Analog output

2 channel version

Menu name		Description
An.output 1 type	•	This menu is used to define the output signal for output 1.
An.output 1 assignmnt	•	The measuring channel to which output 1 is assigned is defined in this menu.
An.output 2 type	•	This menu is used to define the output signal for output 2.
An.output 2 assignmnt	•	The measuring channel to which output 2 is assigned is defined in this menu.
3 channel version		
An.output 3 type	•	This menu is used to define the output

An.output 3 type	•	This menu is used to define the output signal for output 3.
An.output 3 assignmnt	•	The measuring channel to which output 3 is assigned is defined in this menu.
Limit I min.		Parameter for the lower limit of the current output
Limit I max.		Parameter for the upper limit of the current output
I error signal		Parameter for the error signal of the current output
Limit U min.		Parameter for the lower limit of the voltage output
Limit U max.		Parameter for the upper limit of the voltage output
U error signal		Parameter for the error signal of the voltage output
Back	ŧ.	This is the menu exit point. It takes you back to the configuration menu.

The parameters for the type and assignment work in the same way for all channels. Consequently, the parameters are explained below using channel 1 as an example.

This also applies for limit parameters, which are explained using the current signal as an example. If the signal type is changed, the entered parameters for the previous signal are retained.

BA_EN_FT90 93/132

5.4.5.1 Analog output 1 type

Path: \...\An.output 1 type

Level: 3




Fig. 135: Analog output 1 type

The signals can be set for output 1:

Current signals	Voltage signals
0 20 mA	0 10 V
4 20 mA	2 10 V
	1 5 V

5.4.5.2 Analog output 1 assignment

Path: \Configuration\Analog output\An.output 1 assignmnt

Level: 3



Fig. 136: An.output 1 assignment

The assignment of the analog outputs to the channels can be set freely. In the case of a device with two channels, the third channel is hidden.

5.4.5.3 Signal limits

NOTICE! The limit parameters apply for both output signals.

The output signal can by limited by the limit parameters. This primarily serves to prevent error messages in downstream systems caused by brief overstepping of measuring ranges. Due to the fact that the limit parameters for both signal types working the same way, they are only explained for the current signal as this point.

The parameters limit I min., limit I max. and I error signal define the limits of the output signal that may not be undercut or exceeded regardless of the measured variable. These limit values take precedence over the Meas.range C1 start and Meas.range C1 end range defined by the parameter .⁽⁵⁾




Fig. 137: Limitation of the output signal

The value defined via the parameter **I error signal** is issued if the device detects an internal error and can no longer work correctly. It should be noted here that not all potential errors and faults can be detected by the device itself.

Signal range

Current signal	0 21.5 mA
Voltage signal	0 10.5 V

BA_EN_FT90 95/132

⁽⁵⁾ For the second channel, the channel number changes to C2.

5.4.6 Switch output

Path: \Configuration\Switch output

Level: 2




Fig. 138: Switch output

NOTICE! As the configuration for each switch output is the same, only the parameters for the first switch output are shown here.

Menu name		Description
SP1 assignment	•	This menu is used to assign switch output 1 to a channel or to switch it off.
SP1 on		The activation point is set with this parameter.
SP1 off		The deactivation point is defined with this parameter.
SP1 delay on		The activation delay is defined with this parameter.
SP1 delay off		The deactivation delay is defined with this parameter.
SP1 function	•	The contact point is defined with this menu.
	:	
Back	ŧ.	This is the menu exit point. It takes you back to the configuration menu.

5.4.6.1 SP1 assignment

Path: \Configuration\Switch output\SP1 assignment

Level: 3



Fig. 139: SP1 assignment

This menu can be used to assign or deactivate the switch point of a channel.

5.4.6.2 SP1 function

Path: \Configuration\Switch output\SP1 function

Level: 3



Fig. 140: SP1 function

The function of this contact is defined with this parameter.


BA_EN_FT90 97/132

5.4.6.3 Switching function


The function of the individual parameters is explained for all switch points using Switch point 1 as an example.

SP1 On defines the activation point, SP1 Off the deactivation point of switch output 1. The values are shown in the valid unit and set accordingly. The values are shown in the valid unit and set accordingly. Both parameters can be set independently over the entire value range.

If the parameter $SP1 \circ n = SP1 \circ ff$, the contact pulls, if the measured value exceeds the parameter value. If the measured value undercuts the parameter value, the contact drops.



If the parameter SP1 on > SP1 off, the contact pulls, if the measured value exceeds the SP1 on. The contact only drops again if SP1 Off is undercut.



If the parameter SP1 on < SP1 off , the contact pulls, if the measured value lies between the parameter values:

SP1 on < Measured value < SP1 off. Otherwise the contact will drop.




Fig. 141: Switch point setting

Delay

The switching behaviour of the contact can be delayed with the two parameters SP1 delay on and SP1 delay off.




Fig. 142: Delay

Increasing input signal

dropping input signal

5.4.7 Display

Path: \Configuration\Display

Level: 2



Fig. 143: Display

Menu name		Description
Language	•	The menu language can be selected in this menu.
Designation		This parameter can be used to file the designation for the device.
Meas.data display	•	This menu can be used to define which measuring value channel should be displayed.
Col.ch. assignmt	•	This menu can be used to determine which measuring channel controls the colour change.
LCD col.	•	This menu is used to determine the colour of the backlighting and/or their colour change.
LCD lighting		This parameter can be used to switch off the lighting based on a timer.
LCD contr.		This parameter is used to set the contrast for the LC display.
Back	ŧ.	This represents the output (exit) of the menu. Press 'back' to return to the configuration menu.

BA_EN_FT90 99/132

5.4.7.1 Language

Path: \Configuration\Display\Language

Level: 3



Fig. 144: Language

Parameter name	Lang	Language		
German	DE	German language		
English	EN	English language		
Español	ES	Spanish language		
Français	FR	French language		
Italiano	IT	Italian language		
Magyar	HU	Hungarian language		

5.4.7.2 Designation

Path: \Configuration\Display\Designation

Level: 3




Fig. 145: Designation

At this point, a designation for the differential pressure transmitter can be issued. There are 20 digits available. The designation appears on the measured value display.

5.4.7.3 Measuring data display

Path: \Configuration\Display\Meas.data display

Level: 3



Fig. 146: Measuring data display

In this menu the channel, whose measured value is displayed, is defined. This menu item is not shown for 1-channel devices.

5.4.7.4 Colour change assignment

Path: \Configuration\Display\Col.ch. assignment

Level: 3





Fig. 147: Colour change assignment

This menu is used to define the channel that controls the colour change. If multiple channels are selected, the colour change takes place once one of the channels triggers a colour change. The triggering channel is marked with a dot. The indicators are deleted once the green range is entered again.

Two channels are displayed on the operating display. First, channel 2 triggers a green-red colour change. Shortly after, the same colour change is triggered by channel 1.

Event 1: Green-red colour change on channel 2



Event 2: Green-red colour change on channel 1




Fig. 148: Display of measured values (colour change)

Example

5.4.7.5 LCD colour


Path: \Configuration\Display\LCD colour

Level: 3



Fig. 149: LCD colour

The following colours can be selected for the back lighting.



The setting for the switch thresholds of the respective colour change are in the menu item Colour change in the menu for the configuration of the channels.

5.4.7.6 LCD lighting

Path: \Configuration\Display\LCD lighting

Level: 3



Fig. 150: LCD lighting

This parameter is used to define a time period after which the back lighting is switched off once no more input has been entered via the keyboard. The lighting can be switched on again by pressing any button.

NOTICE! The parameter also impacts in the same way on the colour change. When the lighting is switched off, a colour change is only display when a button is pressed.

Values of 0 to 600 s can be entered. The lighting can be switched on permanently with the parameter value 0s.

5.4.7.7 LCD contrast

Path: \Configuration\Display\LCD contrast

Level: 3



Fig. 151: LCD contrast

This parameter can be used to set the contrast for the LC display.

BA_EN_FT90 103/132

5.4.8 Modbus RTU

NOTICE! This menu is only available for devices with a Modbus interface.

Path: \Configuration\Modbus RTU

Level: 2




Fig. 152: Modbus RTU

Menu name		Description
Baud rate	F	The baud rate is set with this menu.
Data format	•	The data format (data, parity, stop-bit) is defined for the transmission with this menu.
Modbus address		The device address is entered with this parameter.
Byte sequence	٠	The byte order for the floating point figure is defined with this menu.
Back	ŧ.	This represents the output (exit) of the menu. Press 'back' to return to the configuration menu.

5.4.8.1 Baud rate

Path: \Configuration\Modbus RTU\Baud rate

Level: 3



Fig. 153: Baud rate

Baud rates	Description
2400 Baud	Options for data transmission.
4800 Baud	
9600 Baud	
14400 Baud	
19200 Baud	
28800 Baud	
38400 Baud	
56000 Baud	
57600 Baud	
115200 Baud	
Back t .	This represents the output (exit) of the menu. Press 'back' to return to the Modbus RTU menu.

5.4.8.2 Data format

Path: \Configuration\Modbus RTU\Data format

Level: 3




Fig. 154: Data format

Data format	Description
8-N-1	8 data-bit – No parity – 1 stop-bit
8-N-2	8 data-bit – No parity – 2 stop-bit
8-0-1	8 data-bit – Odd parity – 1 stop-bit
8-0-2	8 data-bit – Odd parity – 2 stop-bit
8-E-1	8 data-bit – Even parity – 1 stop-bit
8-E-2	8 data-bit – Even parity – 2 stop-bit
Back t .	This represents the output (exit) of the menu. Press 'back' to return to the Modbus RTU menu.

BA_EN_FT90 105/132

5.4.8.3 Modbus address

Path: \Configuration\Modbus RTU\Modbus address

Level: 3




Fig. 155: Modbus address

Addresses from 1 to 247 can be used.

5.4.8.4 Byte order

Path: \Configuration\Modbus RTU\Byte order

Level: 3



Fig. 156: Byte order

Menu name		Description
Big Endian		The highest value byte first (MSB-LSB).
Little Endian		The lowest value byte first (LSB-MSB).
Back	ŧ.	This represents the output (exit) of the menu. Press 'back' to return to the Modbus RTU menu.

The order for the bytes of the floating point figures is defined with this menu.

5.5 Info

Path: \Info Level: 1




Fig. 157: Info

Various information for configuration and setting of the device is provided in this menu.

	Menu name	Description
	Dev.	Device type, serial number
	Revision	Firmware version
	Channel 1	Basic measurement range, spread
	Channel 2	Basic measurement range, spread
3 channel version only	Channel 3	Basic measurement range, spread
	Analogue output	Output signal
	Switch output	Assignment, contact type
Modbus version only	Modbus RTU	Baud rate, data format, address
IO-Link version only	IO-Link	Version, vendor ID, device ID
	Back t	. This represents the output (exit) of the information menu. It takes you back to the main menu.

Information about the device and the configuration are provided in this menu.

BA_EN_FT90 107/132

5.6 Service

Path: \Service Level: 1



Fig. 158: Service

Menu name	Description
Load configuration	The configuration saved in the flash memory of the device is loaded.
Save config.	The configuration is saved in the flash memory of the device.
USB → Config.	The configuration saved on a USB drive is loaded.
Configuration → USB	The configuration is saved to a USB drive.
Factory settings	The configuration is reset to the default setting.
Firmware update	The firmware update saved on a USB drive is performed.
Back t .	This is the exit point of the service menu. It takes you 'Back' to the main menu.

5.6.1 Firmware update

For an update, you will need a USB stick with micro-USB connection or, alternatively, a suitable adapter. The internal USB port is accessible after opening the housing.



A DANGER

Opening the housing on ATEX devices

ATEX devices must never be opened inside potentially explosive areas.




Fig. 159: USB port (example)

If you received the firmware on a FISCHER USB stick, you can immediately start the update. If the update has been supplied as a ZIP archive, unzip the archive to the USB stick's root directory. This creates the right directory structure and you can start the update. If an update is not possible, check whether the "fw" directory exists and the firmware (*.bin) is saved there. Additional files on the stick normally do not disrupt the process and do not need to be deleted.




Fig. 160: Example folder structure

BA_EN_FT90 109/132

Execution

- ▷ Perform the update as follows:
- 1. Open the housing
- 2. Insert the USB stick with the new firmware into the USB port.
- 3. Log in as the user with the right to update firmware.
- 4. Navigate to the Service menu.
- 5. Select the Update firmware menu item and start the update. The update takes place automatically.

NOTICE! Sometimes the USB stick is not correctly recognised. In this case, remove the stick and re-insert it during the update.

- → The new software is now installed. The device restarts once the new firmware has been installed.
- 6. Remove the USB stick and close the housing.
- ► The update is now complete.

5.6.2 Replace the humidity and temperature sensors

The FT90 with the FF12 sensor is supplied with firmware version 1.41. All devices with an older firmware version are still fitted with an FF90 sensor. The FF12 sensor only works with the new software.

The current firmware version of a device can be checked via the Info menu. The new software (from 1.41) allows the connected sensor type [> 61] to be set and queried.

If a sensor is defective, the FF12 is delivered as a spare part.

NOTICE! FF90 sensors can no longer be delivered.

- > To make the replacement, proceed as follows:
- 1. You have the rights to update firmware and change the parameters.
- 2. Update firmware with the current firmware if the firmware version is <1.41.
- 3. Then disconnect the device.
- 4. Remove the old sensor and fir the delivered replacement FF12 sensor.
- 5. Re-connect the power supply.
- 6. Log back in to the device
- 7. Follow the path: \Configuration\Input\Sensor type.
- 8. Select sensor type FF12. (6)
- 9. Exit the configuration and access the operating display again.
- ▶ The sensor replacement is now complete.

BA EN FT90

⁽⁶⁾ From software 1.43, the sensor type (FF90 or FF12) is recognised automatically if the sensor type parameter is set to Standard.

6 Servicing

6.1 Maintenance

The instrument is maintenance-free. We recommend the following regular inspection to guarantee reliable operation and a long service life:

- · Check the function in combination with downstream components.
- · Check the leak-tightness of the pressure connection lines.
- · Check the electrical connections.

The exact test cycles need to be adapted to the operating and environmental conditions. In combination with other devices, the operating instructions for the other devices also need to be observed.

6.2 Transport

The measuring device must be protected against impacts. It should be transported in the original packaging or a suitable transport container.

6.3 Service

All defective or faulty devices should be sent directly to our repair department. Please coordinate all shipments with our sales department.



MARNING

Process media residues

Process media residues in and on dismantled devices can be a hazard to people, animals and the environment. Take adequate preventive measures. If required, the devices must be cleaned thoroughly.

Return the device in the original packaging or a suitable transport container.

6.4 Disposal

WEEE-Reg.-No. DE 31751293





Please help to protect our environment and dispose of the workpieces and packaging materials used in an environmentally friendly manner. Observe the country-specific waste treatment and disposal regulations.

The year of production can be found in the production number (serial number):

P# 23 03618.03.123

Production year 2023

Further information on disposal can be found on our website [www.fischermesstechnik.de]

BA_EN_FT90 111/132

7 Technical data

7.1 General

Type designation		FT90	
Measuring variable		Temperature	
		Humidity	
		Differential pressure	
Measurement principle	Temperature	Band gap	
	Humidity	Capacitive	
	Print	Piezo-resistive	

7.2 Input variables

7.2.1 Temperature and humidity

	Sensor assembly	Temperature measuring range
Possible range	On device	-20 to +70°C
	Offset	-40 to +100°C
		Humidity measuring range
Possible range		0 to +100 %rH

7.2.2 Differential pressure

Asymmetric measuring ranges:

Measuring range		Overload	Bursting pressure	Sensor type
	-20 to +80 Pa	750 mbar	1 bar	Α
	0 to 25 Pa	750 mbar	1 bar	Α
	0 to 40 Pa	750 mbar	1 bar	Α
	0 to 60 Pa	750 mbar	1 bar	Α
0 to 1 mbar	0 to 100 Pa	750 mbar	1 bar	Α
0 to 1.6 mbar	0 to 160 Pa	750 mbar	1 bar	Α
0 to 2.5 mbar	0 to 250 Pa	750 mbar	1 bar	Α
0 to 4 mbar	0 to 400 Pa	100 mbar	200 mbar	В
0 to 4 mbar	0 to 400 Pa	750 mbar	1 bar	A *
0 to 6 mbar	0 to 600 Pa	100 mbar	200 mbar	В
0 to 6 mbar	0 to 600 Pa	750 mbar	1 bar	A *
0 to 10 mbar	0 to 1 kPa	100 mbar	200 mbar	В
0 to 10 mbar	0 to 1 kPa	750 mbar	1 bar	A *
0 to 16 mbar	0 to 1.6 kPa	400 mbar	800 mbar	В
0 to 25 mbar	0 to 2.5 kPa	400 mbar	800 mbar	В
0 to 40 mbar	0 to 4 kPa	400 mbar	800 mbar	В
0 to 60 mbar	0 to 6 kPa	1 bar	2 bar	В
0 to 100 mbar	0 to 10 kPa	1 bar	2 bar	В
0 to 160 mbar	0 to 16 kPa	2.5 bar	5 bar	В
0 to 250 mbar	0 to 25 kPa	2.5 bar	5 bar	В
*\ • •				

 $^{^{^{\}circ}}$ Measuring range with increased overload and bursting pressure capability (see 'Order codes/Special aspects')

Symmetric measuring ranges:

Measuring range		Overload	Bursting pressure	Se	nsor
	-12,5 +12,5 Pa	750 mbar	1 bar	Α	
	-25 to +25 Pa	750 mbar	1 bar	Α	
	-40 to +40 Pa	750 mbar	1 bar	Α	
	-60 to +60 Pa	750 mbar	1 bar	Α	
-1 to +1 mbar	-100 to +100 Pa	750 mbar	1 bar	Α	
-1.6 to +1.6 mbar	-160 to +160 Pa	750 mbar	1 bar	Α	
-2.5 to +2.5 mbar	-250 to +250 Pa	100 mbar	200 mbar	В	
-2.5 to +2.5 mbar	-250 to +250 Pa	750 mbar	1 bar	Α	*
-4 to +4 mbar	-400 to +400 Pa	100 mbar	200 mbar	В	
-4 to +4 mbar	-400 to +400 Pa	750 mbar	1 bar	Α	*
-6 to +6 mbar	-600 to +600 Pa	100 mbar	200 mbar	В	
-6 to +6 mbar	-600 to +600 Pa	750 mbar	1 bar	Α	*
-10 to +10 mbar	-1 to +1 kPa	100 mbar	200 mbar	В	
-10 to +10 mbar	-1 to +1 kPa	750 mbar	1 bar	Α	*
-16 to +16 mbar	-1.6 to +1.6 kPa	400 mbar	800 mbar	В	
-25 to +25 mbar	-2.5 to +2.5 kPa	400 mbar	800 mbar	В	
-40 to +40 mbar	-4 to +4 kPa	400 mbar	800 mbar	В	
-60 to +60 mbar	-6 to +6 kPa	1 bar	2 bar	В	
-100 to +100 mbar	-10 to +10 kPa	1 bar	2 bar	В	
-160 to +160 mbar	-16 to +16 kPa	2.5 bar	5 bar	В	
-250 to +250 mbar	-25 to +25 kPa	2.5 bar	5 bar	В	

^{*)} Measuring range with increased overload and bursting pressure capability (see 'Order codes/Special aspects')

BA_EN_FT90 113/132

7.3 Output sizes

Analog outputs

The number of analogue outputs depends on the device version.

Device version	Temperature Humidity	Temperature Humidity Differential pres- sure
Number of analog outputs	2	3

The output signal can be set in the configuration. Upon delivery, all of the analog outputs are set to the same signal (see the type plate).

Output signal	0 to 20 mA 4 to 20 mA	0 to 10 V 2 to 10 V 1 to 5 V
Signal range	0.0 to 21.5 mA	0.0 to 10.5 V
Load impedance R _L	≤ 600 Ω	≥ 2 kΩ
Turn down	4:1	4:1

Switch outputs

The assignment of the switch outputs to the channels can be configured freely.

Number of switch outputs	4
Туре	Potential-free semiconductor switch (MOS-FET)
Progr. switching function	1-pole open contact (NO) 1-pole break contact (NC)
Max. switching voltage	3 to 32 V AC/DC
Max. switching current	0.25 A
Max. switching output	$8 \text{ W} / 8 \text{ VA}$ $R_{ON} \le 4 \Omega$

7.4 Measuring accuracy

7.4.1 Humidity




Fig. 161: Measurement deviation over the entire temperature range

Measurement deviation	see diagram
Hysteresis	± 1.0 %rH
Typical repeatability	± 0.21 %rH
Long-term stability	≤ 0.25 %rH/year

If the sensor is operated continuously at a humidity of over 80 % rH, the measurement error can still exceed the specified maximum value for some time after the humidity has been quickly reduced.

7.4.2 Temperature

The limit values apply to plastic and all remote mounted sensors.

In order for stainless steel sensors mounted directly on the unit to maintain the specified measuring accuracy, an air flow of min. 0.1 m/s must be ensured.




Fig. 162: Typical measurement deviation of the temperature

Measurement deviation	see diagram
Typical repeatability	± 0.15 °C
Long-term drift	< 0.3 °C/Year

BA_EN_FT90 115/132

7.4.3 Differential pressure

- The specifications for the measurement error include linearity and hysteresis.
- All specifications relate to the basic measuring range (see the type plate) and a compensation range of -20 to +70°C.

Sensor type A

Measuring range		Measuren [%]	nent error	Tc-zero [%/10K]		Tc span [%/10K]	
		Тур.	Max.	Тур.	Max.	Тур.	Max.
	0 to 25 Pa	1.5	2.5	0.5	1.0	0.3	0.6
	0 to 40 Pa	1.0	2.0	0.5	1.0	0.2	0.4
	0 to 60 Pa	0.75	1.5	0.3	0.6	0.2	0.4
0 to 1 mbar	0 to 100 Pa	0.5	1.0	0.3	0.6	0.2	0.4
0 to 1.6 mbar	0 to 160 Pa	0.5	1.0	0.3	0.6	0.2	0.4
0 to 2.5 mbar	0 to 250 Pa	0.5	1.0	0.3	0.6	0.2	0.4
0 to 4 mbar	0 to 400 Pa	0.5	1.0	0.15	0.3	0.05	0.1
0 to 6 mbar	0 to 600 Pa	0.5	0.75	0.15	0.25	0.05	0.1
0 to 10 mbar	0 to 1 kPa	0.25	0.5	0.1	0.2	0.05	0.1
	-20 +80 Pa	0,5	1,0	0,3	0,6	0,2	0,4
	-12,5 +12,5 Pa	1,5	2,5	0,5	1,0	0,3	0,6
	-25 +25 Pa	1,0	2,0	0,4	0,8	0,2	0,4
	-40 to +40 Pa	0.75	1.5	0.3	0.6	0.2	0.4
	-60 to +60 Pa	0.5	1.0	0.3	0.6	0.2	0.4
-1 to +1 mbar	-100 to +100 Pa	0.5	1.0	0.3	0.6	0.2	0.4
-1.6 to +1.6 mbar	-160 to +160 Pa	0.5	1.0	0.3	0.6	0.2	0.4
-2.5 to +2.5 mbar	-250 to +250 Pa	0.5	1.0	0.15	0.3	0.05	0.1
-4 to +4 mbar	-400 to +400 Pa	0.5	1.0	0.1	0.2	0.05	0.1
-6 to +6 mbar	-600 to +600 Pa	0.5	0.75	0.1	0.15	0.05	0.1
-10 to +10 mbar	-1 to +1 kPa	0.25	0.5	0.05	0.1	0.05	0.1

Sensor type B

Measuring range		Measuren [%]	nent error	Tc-zero [%/10K]		Tc span [%/10K]	
		Тур.	Max.	Тур.	Max.	Тур.	Max.
0 to 4 mbar	0 to 400 Pa	0.5	1.0	0.15	0.3	0.05	0.1
0 to 6 mbar	0 to 600 Pa	0.5	0.75	0.15	0.25	0.05	0.1
0 to 10 mbar	0 to 1 kPa	0.25	0.5	0.1	0.2	0.05	0.1
0 to 16 mbar	0 to 1.6 kPa	0.25	0.5	0.15	0.3	0.05	0.1
0 to 25 mbar	0 to 2.5 kPa	0.25	0.5	0.15	0.25	0.05	0.1
0 to 40 mbar	0 to 4 kPa	0.25	0.5	0.1	0.2	0.05	0.1
0 to 60 mbar	0 to 6 kPa	0.25	0.5	0.1	0.2	0.05	0.1
0 to 100 mbar	0 to 10 kPa	0.25	0.5	0.1	0.15	0.05	0.1
0 to 160 mbar	0 to 16 kPa	0.25	0.5	0.05	0.1	0.05	0.1
0 to 250 mbar	0 to 25 kPa	0.25	0.5	0.05	0.1	0.05	0.1
-2.5 to +2.5 mbar	-250 to +250 Pa	0.5	1.0	0.15	0.3	0.05	0.1
-4 to +4 mbar	-400 to +400 Pa	0.5	1.0	0.1	0.2	0.05	0.1
-6 to +6 mbar	-600 to +600 Pa	0.5	0.75	0.1	0.15	0.05	0.1
-10 to +10 mbar	-1 to +1 kPa	0.25	0.5	0.05	0.1	0.05	0.1
-16 to +16 mbar	-1.6 to +1.6 kPa	0.25	0.5	0.1	0.2	0.05	0.1
-25 to +25 mbar	-2.5 to +2.5 kPa	0.25	0.5	0.1	0.15	0.05	0.1
-40 to +40 mbar	-4 to +4 kPa	0.25	0.5	0.05	0.1	0.05	0.1
-60 to +60 mbar	-6 to +6 kPa	0.25	0.5	0.05	0.1	0.05	0.1
-100 to +100 mbar	-10 to +10 kPa	0.25	0.5	0.05	0.1	0.05	0.1
-160 to +160 mbar	-16 to +16 kPa	0.25	0.5	0.05	0.1	0.05	0.1
-250 to +250 mbar	-25 to +25 kPa	0.25	0.5	0.05	0.1	0.05	0.1

BA_EN_FT90 117/132

7.5 Digital interfaces

USB interface

USB On The Go	2.0
Data rate	12 Mbit/s (Full Speed)
Connection	Micro USB type B
Communication	Host/Device mode

Modbus RTU interface

interface	RS 485
Report	Modbus RTU
Modbus specification	Application Protocol Specification V1.1b3 (26 April 2012)
Address	1 247
Baud rate	2400 115200 baud
Parity	Even, uneven, parity
Stop bits	12

IO-Link Interface

Connection	M12-4 Class A
IO-Link specification	V1.1
Pin assignment	as per IEC 60974-5-2
Device energy supply	max. 200 mA
Data transmission rates	COM 2 = 38.4 kBd

7.6 Auxiliary energy

NOTICE! Only a CE-compliant mains adapter with a slow 200 mA fuse may be used in the power supply circuit for ATEX devices.

Nominal voltage	24 V AC/DC
Admissible operating voltage U _b	19.2 to 28.8 V AC/DC
Power consumption	Typ. 2W (VA)
	Max. 3W (VA)

7.7 Operating conditions

	Standard	ATEX		
Ambient temperature range	-20 to +70 °C	-20 to +60 °C		
Medium temperature range	-20 to +70 °C	-20 to +60 °C		
Storage temperature range	-20 to +70 °C	-20 to +70 °C		
Ingress Protection Code	IP65	IP65		
EMC	EN 61326-1:2013 EN 61326-2-3:2013			
ATEX	EN IEC 60079-0:2018 EN 60079-15:2010 EN 60079-31			
RoHS	EN IEC 63000:2018			

CAUTION! Avoid contact between the temperature/humidity sensor and the following chemicals and substances:

- Contaminated air/air that is not oil-free (e.g. jets of air from an air gun)
- · Volatile chemicals such as solvents and organic (carbonated) compounds

- Ketene, acetone, ethanol, isopropyl alcohol, toluene and so on are known for causing a drift in the measured humidity value. In most cases, this is not reversible. Please note that these chemicals are integral parts of epoxides, adhesives, glues etc. and can degas during baking/curing.
- Acids and bases such as HCl, H2SO4, HNO3, and NH3 can affect the sensor irreversibly, and should be avoided. Ozone in high concentrations or H2O2 has the same effect and should also be avoided.
- The sensor must not be allowed to come into contact with cleaning agents (e.g. alcohol and detergents). The application of cleaning agents to the sensor can cause the measured value to drift or the sensor to fail completely.

7.8 Display

Display	Full graphic LC display
Resolution	128 x 64 Pixel
Backlight	RGB
Measured value display	6 digits

7.9 Construction design

Process connection		Outer Ø	Inner Ø
CK screw connections made of aluminium	Hose	6 mm	4 mm
	Hose	8 mm	6 mm
Pneumatic connector socket in nickel-plated brass	Hose	6 mm	4 mm
	Hose	8 mm	6 mm
Cutting ring connection in stainless steel	Pipe	6 mm	
	Pipe	8 mm	

Electrical connection	
Devices with analog and switch outputs	
Connector 1 : Auxiliary energy, output	5-pin male
Connector 2 : Switch outputs	8-pin male
Connector 3: Temperature/humidity sensor	4-pin female
Device with Modbus	
Connector 1: Modbus IN	5-pin male
Connector 2: Modbus OUT	5-pin female
Connector 3: Temperature/humidity sensor	4-pin female

Installation position	User-defined
Dimensions (without connections)	120 x 81.5 x 95 mm
Weight	Max. 380 g

BA_EN_FT90 119/132


7.9.1 Materials

Materials of the parts in contact with the medium				
Pressure sensor	Silicon, PVC, FKM, aluminium, brass, stainless steel			
FF12FK	PBT (20% GF), stainless steel, FR4, solder resist, silicon, tin, copper, nickel, silver, ceramic			
FF12FE	PBT (20% GF), stainless steel, PTFE, FR4, solder resist, silicon, tin, copper, nickel, silver, ceramic			
FF12FV	Stainless steel, FR4, solder resist, silicon, tin, copper, nickel, silver, ceramic			
FF12FP	Stainless steel, PTFE, FR4, solder resist, silicon, tin, copper, nickel, silver, ceramic			

Materials of the parts in contact with the environment				
All versions	Polyester, PET, polyamide 6.6, aluminium, nickel-plated brass, stainless steel			
Sensor connection ATEX	Zinc alloy, nickel-plated			

7.9.2 Dimensional drawings

All dimensions in mm unless otherwise stated






Fig. 163: Dimensional drawing

Mounting rail




Fig. 164: Mounting rail

BA_EN_FT90 121/132

Process connection





Fig. 165: Options for the process connection

Process connection		D	d	L	SW1	SW2	SW3
Cutting ring screw connection	screw connection Pipe			23.5	14	14	14
				24.5	14	17	14
CK screw connection	on Hose		4	21	14	12	
		8	6	21	14	14	
Pneumatic plug-in connection	ection Pneumatic		4	18	14	11	
hose		8	6	20.5	14	13	

D: Outer diameter; d: Inner diameter

8 Order code



Differential pressure measuring range:

[1,2]		[1,2]		[1,2]	
00	Without differential pre	ssure m	easuring		
		D1	0 25 Pa		
		D2	0 40 Pa		
		D3	0 60 Pa		
51	0 1 mbar	D4	0 100 Pa		
97	0 1,6 mbar	D5	0 160 Pa		
98	0 2,5 mbar	D6	0 250 Pa		
52	0 4 mbar	D7	0 400 Pa		
53	0 6 mbar	D8	0 600 Pa		
54	0 10 mbar	N1	0 1 kPa	D9	0 1000 Pa
55	0 16 mbar	N2	0 1,6 kPa	E1	0 1600 Pa
56	0 25 mbar	N3	0 2,5 kPa	E2	0 2500 Pa
57	0 40 mbar	N4	0 4 kPa	E 3	0 4000 Pa
58	0 60 mbar	N5	0 6 kPa	E4	0 6000 Pa
59	0 100 mbar	E5	0 10 kPa	1P	0 10000 Pa
60	0 160 mbar	E6	0 16 kPa	2P	0 16000 Pa
82	0 250 mbar	E7	0 25 kPa	3P	0 25000 Pa
		L0	-20 +80 Pa		
		L4	-12,5 +12,5 Pa		
		L5	-25 +25 Pa		
		R6	-40 +40 Pa		
		2L	-60 +60 Pa		
A4	-1 +1 mbar	L7	-100 +100 Pa		
A5	-1,6 +16 mbar	R7	-160 +160 Pa		
A6	-2,5 +2,5 mbar	L6	-250 +250 Pa		
A7	-4 +4 mbar	R1	-400 +400 Pa		
A8	-6 +6 mbar	R2	-600 +600 Pa		
A9	-10 +10 mbar	L8	-1 +1 kPa		
B1	-16 +16 mbar	L9	-1,6 +1,6 kPa		
B2	-25 +25 mbar	M6	-2,5 +2,5 kPa		
C5	-40 +40 mbar	M7	-4 +4 kPa		
В3	-60 +60 mbar	M8	-6 +6 kPa		
B4	-100 +100 mbar	R8	-10 +10 kPa		
R5	-160 +160 mbar	R9	-16 +16 kPa		

BA_EN_FT90 123/132

[1,2]		[1,2]		[1,2]
B6	-250 +250 mbar	T1	-25 +25 kPa	

Humidity and temperature measuring range:

[3,4]	Measuring range	Sensor material
10	Humidity 0 to 100% rH Temperature -40 to 100°C	Plastic with stainless steel filter
20	Humidity 0 to 100% rH Temperature -40 to 100°C	Stainless steel with stainless steel filter
30	Humidity 0 to 100% rH Temperature -40 to 100°C	Stainless steel with PTFE Filter
40	Humidity 0 to 100% rH Temperature -40 to 100°C	Plastic with PTFE Filter

Process connection:

[5,6]	
00	without
18	G⅓ female thread (aluminium)
40	Aluminium CK screw connection for 6/4 mm hose
41	Aluminium CK screw connection for 8/6 mm hose
P6	Nickel-plated brass pneumatic plug-in connector for 6/4 mm hose
P8	Nickel-plated brass pneumatic plug-in connector for 8/6 mm hose
24	Stainless steel cutting ring connection for 6 mm pipe
25	Stainless steel cutting ring connection for 8 mm pipe

Output signal:

[7]	
0	without
Switch	nable, factory pre-set:
С	0 10 V
Α	0 20 mA
Р	4 20 mA
Digital	Interface:
M	RS485 Modbus RTU (without switching outputs)
N	RS485 Modbus RTU (with 4 switching outputs)
I	IO-Link (with 4 switching outputs)

Special functions:

[8]	
0	None

Special aspects:

[9]				
0	None			
1		or with increased overload an only for the following pressur		
	52	0 to 4 mbar	D7	0 to 400 Pa
	53	0 to 6 mbar	D8	0 to 600 Pa
	54	0 to 10 mbar	N1	0 to 1 kPa
	A6	-2.5 to +2.5 mbar	L6	-250 to +250 Pa
	A 7	-4 to +4 mbar	R1	-400 to +400 Pa

[9]				
	A8	-6 to +6 mbar	R2	-600 to +600 Pa
	A9	-10 to +10 mbar	L8	-1 to +1 kPa

Approval and housing/lid colour:

[13,14]	Approval	Housing colour	Lid colour
00	None	Anthracite	Green
R1	ATEX zones 2 and 22		Black
		(conductive housing)	

Membrane keypad:

[15]	
0	FISCHER
1	Neutral

Configuration:

[16]	Preset at the factory *)
0	'Standard' configuration
Z	'Customer-specific' configuration

^{*)} The configuration can be changed on the device at any time. The delivery state is defined by the order code. For details, see the operating instructions.

8.1 Accessories

M12 connection cables

Designation	No. of poles	Length	Order no.
PUR connection cable with M12 coupling,	4 poles	2 m	06401993
A-coded		5 m	06401994
		7 m	06401563
		10 m	06401572
	5 poles	2 m	06401995
		5 m	06401996
		7 m	06401564
		10 m	06401573
	8 poles	2 m	09001844
		5 m	09011146
		10 m	09011016

Connection cables for humidity and temperature sensor

Designation	No. of poles	Length	Order no.
M12 coupling/M12 straight connector,	4 poles	2 m	09011363
A-coded		5 m	09011364
		10 m	09011365
		15 m	09011366

Mounting flange for ventilation ducts

	Universal fland	ge for square and round pipes	06411826
--	-----------------	-------------------------------	----------

BA_EN_FT90 125/132




Fig. 166: Universal mounting flange for humidity and temperature sensors

Spare parts

FF12 humidity and temperature sensor	Order no.
Smooth sensor made from plastic with stainless steel filter	FF12 FK
Smooth sensor made from stainless steel with stainless steel filter	FF12 FV
Smooth sensor made from stainless steel with PTFE Filter	FF12 FP
Smooth sensor made from plastic with PTFE Filter	FF12 FE

USB interface

Designation		Order no.
Connection cable, USB-A on USB micro-B connector	2 m	09007340
Stick USB 2.0, USB-A/micro-B connector	16 GB	09007316

Modbus

Designation		Order no.
Modbus terminating resistor	120 ohm socket	06411280
	120 ohm connector	06411279

Software

The configuration software in Touch is available at $\underline{\text{fischermesstechnik.de}}$ as a download.

Accessories for outdoor use

Designation	Material	Order No.
Canopy	Stainless steel	02006130

Software

The inTouch configuration software is available for download on our website (fischermesstechnik.de).

9 Attachments

9.1 EU Declaration of Conformity



(Translation) **CE**

EU Declaration of Conformity

For the product described as follows

Product designation

Humidity and temperature measuring device

Type designation

FT90 ... 00##

it is hereby declared that it corresponds with the basic requirements specified in the following designated directives:

RoHS Directive

2011/65/EU (EU) 2015/863

Delegated Directive amending Annex II to Directive 2011/65/EU

The products were tested in compliance with the following standards.

Electromagnetic compatibility (EMC)

DIN EN 61326-1:2013-07

Electrical equipment for measurement, control and laboratory use - EMC requirements - Part

EN 61326-1:2013 DIN EN 61326-2-3:2013-07

EN 61326-2-3:2013

Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 2-3: Particular requirements - Test configuration, operational conditions and performance criteria for transducers with integrated or remote signal conditioning

RoHS Directive (RoHS3)

DIN EN IEC 63000:2019-05 EN IEC 63000:2018

Technical documentation for the assessment of electrical and electronic products with re-

spect to the restriction of hazardous substances

Also they were subjected to the conformity assessment procedure "Internal production control".

Sole responsibility for the issue of this declaration of conformity in relation to fulfilment of the fundamental requirements and the production of the technical documents is with the manufacturer.

Manufacturer

FISCHER Mess- und Regeltechnik GmbH

Bielefelder Str. 37a

32107 Bad Salzuflen, Germany

Tel. +49 (0)5222 974 0

Documentation representative

Torsten Malischewski General Manager R&D

The devices bear the following marking:

CE

Bad Salzuflen 25 Okt 2022

T. Malischewski General manager R&D

09010422 • CE_EN_FT90 • Rev. ST4-B • 10/22

Fig. 167: CE DE FT90



(Translation) (E

EU Declaration of Conformity

For the product described as follows

Product designation

Humidity and temperature measuring device

Type designation

FT90 ... R1##

it is hereby declared that it corresponds with the basic requirements specified in the following designated directives:

2014/30/EU EMC Directive 2014/34/EU ATEX Directive 2011/65/EU RoHS Directive

(EU) 2015/863 Delegated Directive amending Annex II to Directive 2011/65/EU

The products were tested in compliance with the following standards.

Electromagnetic compatibility (EMC)

DIN EN 61326-1:2013-07 EN 61326-1:2013

Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 1: General requirements

DIN EN 61326-2-3:2013-07

Electrical equipment for measurement, control and laboratory use - EMC requirements - Part

EN 61326-2-3:2013

2-3: Particular requirements - Test configuration, operational conditions and performance

criteria for transducers with integrated or remote signal conditioning

Explosive atmospheres (ATEX)

DIN EN IEC 60079-0:2019-09

EN IEC 60079-0:2018

Explosive atmospheres - Part 0: Equipment - General requirements

DIN EN IEC 60079-7/A1:2018-07 EN IEC 60079-7:2015/A1:2018

Explosive atmospheres - Part 7: Equipment protection by increased safety "e" (IEC 60079-7:2015/A1:2017)

DIN EN 60079-31:2014-12 EN 60079-31:2014

Explosive atmospheres - Part 31: Equipment dust ignition protection by enclosure "t"

RoHS Directive (RoHS 3)

DIN EN IEC 63000:2019-05

EN IEC 63000:2018

Technical documentation for the assessment of electrical and electronic products with re-

spect to the restriction of hazardous substances

Also they were subjected to the conformity assessment procedure "Internal production control".

Sole responsibility for the issue of this declaration of conformity in relation to fulfilment of the fundamental requirements and the production of the technical documents is with the manufacturer.

Manufacturer

FISCHER Mess- und Regeltechnik GmbH

Bielefelder Str. 37a

32107 Bad Salzuflen, Germany

Tel. +49 (0)5222 974 0

Documentation representative

Torsten Malischewski General Manager R&D

The devices bear the following marking:

Zone 2

Zone 22

Bad Salzuflen 25 Okt 2022

T. Malischewski General manager R&D

09010424 • CE_EN_FT90_ATEX • Rev. ST4-B • 10/22

Fig. 168: CE DE FT90 ATEX

9.2 UKCA Declaration of Conformity







UKCA Declaration of Conformity

For the product described as follows

Product designation

Humidity and temperature measuring device

Type designation

FT90 ... 00##

is hereby declared to comply with the essential requirements, specified in the following UK regulations:

Statutory regulation No.

Description

2016 No. 1091

The Electromagnetic Compatibility Regulations 2016

2021 No. 422

The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic

Equipment (Amendment) Regulations 2021

2022 No. 1647

The Hazardous Substances and Packaging (Legislative Functions and Amendment) (EU

Exit) Regulations 2020

The products have been tested according to the following standards.

Electromagnetic compatibility (EMC):

BS EN 61326-1:2013-02-28

Electrical equipment for measurement, control and laboratory use. EMC requirements. Gen-

eral requirements

BS EN 61326-2-3:2013-02-28

Electrical equipment for measurement, control and laboratory use. EMC requirements. Particular requirements. Test configuration, operational conditions and performance criteria for

transducers with integrated or remote signal conditioning.

Restriction of Hazardous Substances (RoHS):

BS EN IEC 63000:2018-12-10

Technical documentation for the assessment of electrical and electronic products with re-

spect to the restriction of hazardous substances

The sole responsibility for drawing up this declaration of conformity in relation to the fulfilment of the essential requirements and the preparation of the technical documentation lies with the manufacturer.

Manufacturer

FISCHER Mess- und Regeltechnik GmbH

Bielefelder Str. 37a

32107 Bad Salzuflen, Germany

Tel. +49 (0)5222 974 0

The devices bear the following marking:

CA

Bad Salzuflen 25 Okt 2022 T. Malischewski

General manager R&D

09010787 • UKCA_EN_FT90 • Rev. ST4-A • 10/22

Fig. 169: UKCA EN FT90







UKCA Declaration of Conformity

For the product described as follows

Product designation

Humidity and temperature measuring device

Type designation

FT90 ... R1##

is hereby declared to comply with the essential requirements, specified in the following UK regulations:

Statutory regulation No.

Description

2016 No. 1107

The Equipment and Protective Systems Intended for Use in Potentially Explosive Atmo-

spheres Regulations 2016

2016 No. 1091

The Electromagnetic Compatibility Regulations 2016

2021 No. 422

The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic

Equipment (Amendment) Regulations 2021

2022 No. 1647

The Hazardous Substances and Packaging (Legislative Functions and Amendment) (EU

Exit) Regulations 2020

The products have been tested according to the following standards.

Explosive atmospheres (ATEX):

BS EN IEC 60079-0:2018-07-09

Explosive atmospheres. Equipment. General requirements

BS EN IEC 60079-15:2019-05-03 BS EN 60079-31:2014-07-31 Explosive atmospheres. Equipment protection by type of protection "n" Explosive atmospheres. Equipment dust ignition protection by enclosure "t"

Electromagnetic compatibility (EMC):

BS EN 61326-1:2013-02-28

Electrical equipment for measurement, control and laboratory use. EMC requirements. Gen-

eral requirements

BS EN 61326-2-3:2013-02-28

Electrical equipment for measurement, control and laboratory use. EMC requirements. Particular requirements. Test configuration, operational conditions and performance criteria for transducers with integrated or remote signal conditioning.

Restriction of Hazardous Substances (RoHS):

BS EN IEC 63000:2018-12-10 Technical doc

Technical documentation for the assessment of electrical and electronic products with re-

spect to the restriction of hazardous substances

The sole responsibility for drawing up this declaration of conformity in relation to the fulfilment of the essential requirements and the preparation of the technical documentation lies with the manufacturer.

Manufacturer

FISCHER Mess- und Regeltechnik GmbH

Bielefelder Str. 37a

32107 Bad Salzuflen, Germany

Tel. +49 (0)5222 974 0

The devices bear the following marking:

UK

Zone 2

Zone 22

Bad Salzuflen 25 Okt 2022

Fig. 170: UKCA EN FT90 ATEX

T. Malischewski General manager R&D

09010789 • UKCA EN_FT90_ATEX • Rev. ST4-A • 10/22

Notes

BA_EN_FT90 131/132







FISCHER Mess- und Regeltechnik GmbH

Bielefelder Str. 37a D-32107 Bad Salzuflen

Tel. +49 5222 974-0 Fax +49 5222 7170 www.fischermesstechnik.de info@fischermesstechnik.de